




OWNER'S MANUAL

SAVE THESE INSTRUCTIONS

PRO20-012 Pump Only 12-Volt DC



DO NOT RETURN THIS PRODUCT TO THE STORE!

Please contact Great Plains Industries before returning any product. If you are missing parts or experience problems with your installation, our **Customer Support Department** will be happy to assist you:

800-835-0113 or
316-686-7361




TABLE OF CONTENTS

General Information.....	2
Installation	2
Operation.....	3
Maintenance	4
Troubleshooting.....	5
Specifications	6
Parts and Service	6
Illustrated Parts Drawing	7
Warranty	See Insert

To the owner...

Congratulations on receiving your GPRO® Fuel Transfer Pump. We are pleased to provide you with a system designed to give you maximum reliability and efficiency.

Your fuel pump is designed, tested, and approved for use with gasoline (up to 15% alcohol blends such as E15), diesel fuel (up to 20% biodiesel blends such as B20) and kerosene. Please take all due precautions when handling these flammable liquids. Your safety is important to us.

Also, to assure the longest possible service life, it is important that you follow the operation and maintenance procedures outlined in this manual. We are proud to provide you with a quality product and dedicated support. Together with your conscientious use, we are sure that you will obtain years of safe, dependable service.



Victor Lukic

Victor Lukic, President
Great Plains Industries, Inc.

GENERAL INFORMATION

The purpose of this manual is to assist you in installing, operating and maintaining your GPRO® pump. This manual covers 12-volt DC model PRO20-012.

Model Components

PRO20-012PO: Includes pump only.



An automatic bypass valve prevents pressure build up when the pump is on with the nozzle closed. To avoid damage, do not run the pump more than 10 minutes with the nozzle closed.

The duty cycle of this pump is 30 minutes ON and 30 minutes OFF. Allow the pump to cool for 30 minutes.

This pump is designed for use **only** with gasoline (up to 15% alcohol blends such as E15), diesel fuel (up to 20% biodiesel blends such as B20) and kerosene. **Do not** use this pump for dispensing any fluids other than those for which it was designed. To do so may damage pump components and will void the warranty.

This pump is designed to operate on a typical DC automotive electrical system. The pump is designed to operate with the appropriate DC voltage at the motor leads and the ratings are determined at this voltage. Performance may vary due to length of power cord, battery condition or output from the vehicle charging system that will affect system voltage.

Do not leave the system running with fluids. "Dry running" can damage the pump.

Do not pump the tank completely dry, as contaminants from the bottom of the tank may enter the pump.

SAFETY INSTRUCTIONS



The following safety alert symbols are used in this manual.

DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

CAUTION indicates a hazardous situation which, if not avoided, may result in minor or moderate injury.

It is your responsibility to:

- Know and follow applicable national, state and local safety codes pertaining to installing and operating electrical equipment for use with flammable liquids.
- Know and follow all safety precautions when handling petroleum fuels.
- Ensure that all equipment operators have access to adequate instructions concerning safe operating and maintenance procedures.

Observe all safety precautions concerning safe handling of petroleum fuels.

To ensure safe operation, all fuel transfer systems must be properly grounded. Proper grounding means a continuous metal-to-metal contact from one component to the next, including tank, bung, pump, meter, filter, hose and nozzle. Care should be taken to ensure proper grounding during initial installation and after any service or repair procedures. For your safety, please take a moment to review the warnings below.

To prevent physical injury, observe precautions against fire or explosion when dispensing fuel. Do not operate the system in the presence of any source of ignition including running or hot engines, lighted cigarettes, or gas or electric heaters.

Observe precautions against electrical shock when operating the system. Serious or fatal shock can result from operating electrical equipment in damp or wet locations.

Inspect external pump wiring regularly to make sure it is correctly attached to the battery. To avoid electrical shock, use extra care when connecting the pump to power.

Avoid prolonged skin contact with petroleum fuels. Use protective goggles, gloves and aprons in case of splashing or spills. Change saturated clothing and wash skin promptly with soap and water.

Observe precautions against electrical shock when servicing the pump. **Always** disconnect power before repairing or servicing. **Never** apply electrical power to the system when any of the coverplates are removed.

If using solvent to clean pump components or tank, observe the solvent manufacturer's recommendations for safe use and disposal.

INSTALLATION

Install Suction Pipe

Your pump is designed to mount directly to a standard 2 in. NPT tank fitting. Apply thread tape to the suction pipe thread and securely tighten the suction pipe to the pump inlet port.

Make sure any check valve or foot valves used are equipped with proper pressure relief valves.

Install Pump on Tank

- Clean the tank interior of all dirt and foreign material.
- Place the pump with suction pipe installed on the tank fitting and tighten securely. Make sure the pump is not cross-threaded.
- To prevent pressure build-up and possible fuel leaks through the nozzle, make sure the tank is vented. A vent cap rated at 3 psi or less is recommended.

Install Electrical Connections


The PRO20-012 must be connected to a 12-volt DC power source only.

DO NOT attempt to connect this pump to a 115-volt AC or 230-volt AC power source.


For installation in unclassified areas, the supplied power cord, fuse and strain relief grip may be used.

NOTE: These components have not been evaluated as part of the UL Listed Equipment and are not intended for use in a Hazardous (Classified) Location.

To install the power cord, remove the electrical coverplate. (Figure 1)



Trim the power cord to the desired length. If your power cord is not pre-stripped, strip 3 inches of outer insulation from the power cord end. Then strip 1/2 inch of insulation from the power cord wires. Slide the strain relief grip onto the power cord so that the threaded end of the strain relief grip faces the stripped power wires. (Figure 2)



Insert the power cord through the 3/4 inch NPT connection on the side of the electrical box.

Using wire nuts, connect the black wire to the black wire and the white (or red) wire to the white (or red) wire in the pump's electrical cavity. Position the wires inside the electrical cavity and tighten the strain relief grip securely. Make sure surfaces are clean. Install the coverplate and tighten securely.

⚠ WARNING

Carefully route the power cord to the battery, protecting the power cord from hot surfaces, sharp edges or anything that could damage the power cord, resulting in a short circuit.

A fuse is provided to protect the power cord and motor. Install fuse in the white (or red) wire of the power cord as close as possible to the battery. Connect the red wire of the fuse to the positive (ungrounded) side of battery. Connect black wire to the negative (grounded) side of the battery.

Failure to follow these instruction could result in death, serious injury or loss of equipment due to short circuit, fire or explosion.

⚠ DANGER

If the pump is to be installed in a Hazardous (Classified) location, it must be installed by a licensed electrician and conform to National Fire Protection Association (NFPA) codes 30 and 70. You, as the owner, are responsible for seeing that the installation and operation of your pump complies with NFPA codes as well as any applicable state and local codes. Rigid conduit must be used to install wiring. Note that the lead wires are factory-sealed isolating the motor from the junction box.

Failure to follow these wiring instructions may result in death or serious injury from shock, fire or explosion.

Install Hose and Nozzle

All threaded fuel connections must be sealed with thread tape or a pipe thread sealing compound approved for use with petroleum fuels.

After sealing the threads, tighten the hose into the pump outlet and the nozzle on the hose. The nozzle can be placed in the nozzle holder only when the pump is off.

The nozzle holder allows the pump to be locked when the nozzle is in place.

OPERATION

ALWAYS FOLLOW SAFETY PRECAUTIONS WHEN OPERATING THIS EQUIPMENT. REVIEW THE SAFETY INSTRUCTIONS. Before each use, repair leaks around seals or connections. Make sure hoses are in good condition and connections are tight. Make sure the work area is dry. Make sure the pump is properly grounded. Repair any corroded or damaged wiring before use. Ensure the tank contains enough fuel. Make sure the fuel is not contaminated with debris.

Dispense Fuel

Turn the pump on by removing the nozzle from its holder and pulling back on the switch lever. Insert the nozzle into the receiving tank and squeeze the handle to start fuel flow. When done, release the nozzle handle.

After dispensing fuel, push the switch lever forward to turn the pump off and return the nozzle to the holder. The nozzle may be locked in place to prevent unauthorized use by installing a padlock (not provided) through the hole in the top of the nozzle cover.



The pump is designed to be self-priming. If fuel is not delivered within 15 to 20 seconds, turn the pump off and refer to the priming information in the Troubleshooting Section.

An automatic bypass valve prevents pressure buildup when the pump is on with the nozzle closed. To avoid pump damage, do not run the pump for more than 10 minutes with the nozzle closed.

Motor Protector

This pump is equipped with a motor protective device that also serves as the ON / OFF switch.

NOTE: The motor protective device is not intended to provide branch circuit protection.

- If motor is overloaded, the protective device trips and opens the circuit. This feature protects the motor from damage and must be reset manually.
- To reset, turn the switch lever off and then back on.
- If the protective device trips again quickly, turn the power off at the source before attempting to troubleshoot the problem. Follow instructions as described in the Troubleshooting Section of this manual.
- Make sure the switch lever is off before restoring power.
- Turn the switch lever on and restart.

MAINTENANCE


This pump is designed for minimum maintenance. Motor bearings are sealed and require no lubrication. Inspect the pump and components regularly for fuel leaks and make sure the hose and power cord are in good condition. Keep the pump exterior clean to help identify leaks.

Do not use this pump for water, chemicals or herbicides.

Dispensing any fluid other than those listed in this manual will damage the pump. Use of the pump with unauthorized fluids will void the warranty.

To Clean or Replace Strainer

All pump models have an inlet strainer. If flowrate is reduced, clean or replace strainer (see below).



Turn the pump off and disconnect from power. Remove and clean the strainer with a soft-bristled brush and solvent. If the strainer is very dirty, compressed air may be used. If damaged, replace the strainer.

Replace components making sure that they are seated and fasteners are tightened securely.

REPAIR

Carefully inspect all parts for wear or damage. Replace components as necessary. The Illustrated Parts List gives information on replacement parts and kits.

Review the Safety Instructions before proceeding.

⚠ WARNING

Observe precautions against electrical shock when servicing the pump. **Always** disconnect power before repairing or servicing. **Never** apply electrical power to the system when any of the coverplates are removed..

⚠ CAUTION

Avoid prolonged skin contact with petroleum fuels. Use protective goggles, gloves and aprons in case of splashing or spills. Change saturated clothing and wash skin promptly with soap and water.

TROUBLESHOOTING

SYMPTOM	PROBABLE CAUSE	CORRECTIVE ACTION
A. MOTOR DOES NOT RUN	1. Wiring problem 2. Fuse blown 3. Rotor or vanes jammed 4. Circuit breaker switch defective 5. Motor bad	Confirm all connections are tight and correct voltage is getting to the pump. Inspect fuse in fuse holder on power cord. If blown, replace. Remove coverplate to expose rotor. Remove any obstructions. Check for excessive vane and slot wear. If damaged, replace. Replace switch. Contact the factory.
B. MOTOR RUNS BUT DOES NOT PUMP FLUID	1. Tank level low 2. Clogged filter assembly 3. Suction line problem 4. Broken motor shaft key 5. Bypass poppet stuck open 6. Motor running backwards	Add fuel to tank. Remove and clean filter assembly or replace. Remove suction pipe and remove any obstructions. Replace shaft key in end of shaft. Check slot and vane for excessive wear. Remove any obstructions. Remove bypass poppet and clean. If damaged, replace. Check wiring to confirm correct polarity.
C. PUMP FAILS TO PRIME	1. Air leak in system 2. Bypass poppet stuck open 3. Vanes worn or sticking 4. Motor runs backwards	Check for air leaks at all joints. Reseal and tighten. Remove bypass poppet and clean. If damaged, replace. Check slots and vanes for excessive wear or damage. If damaged, replace. Check wiring to confirm correct polarity
D. LOW FLOWRATE	1. Low voltage 2. Wiring problem 3. Clogged filter assembly 4. Air leak in system 5. Bypass poppet stuck open 6. Vanes worn or sticking 7. Outlet is blocked 8. Clogged or broken suction pipe 9. Fuel level low 10. Using off-the-shelf automatic nozzle 11. Hose damaged	Check battery voltage. Confirm voltage is correct. Confirm correct polarity and all connections are tight. Confirm wire size is correct and not too small. Remove and clean filter assembly or replace. Check for air leaks at all joints. Reseal and tighten. Remove bypass poppet and clean. If damaged, replace. Remove any obstructions. Check rotor slots and vanes for excessive wear. Replace if damaged. Check all accessories for blockage. Remove any obstructions. Remove pump and clear suction pipe, replace as needed. Fill tank. Factory-supplied automatic nozzle is recommended. Replace hose.
E. MOTOR STALLS WHEN NOZZLE IS CLOSED	1. Bypass poppet stuck closed 2. Rotor or vanes worn 3. Low voltage 4. Motor defective	Remove bypass poppet and clean or replace as needed. Check rotor and vanes for excessive wear. Replace as needed. Check incoming battery voltage and tighten wiring connections. UL Listing requires specific treatment for motor replacement, contact factory.
F. FUEL LEAKAGE	1. Threaded joints loose 2. Insufficient bolt torque 3. Lost or damaged O-rings 4. Shaft seal worn or damaged 5. Hose damaged	Check and reseal threaded joints. Retighten bolts. Check O-rings for damage. Replace as needed. Fuel leaking from drain hole indicates shaft seal needs to be replaced. Replace hose.
G. MOTOR OVERHEATS	1. Pumping high viscosity fluids 2. Clogged filter assembly 3. Clogged or broken suction pipe 4. Duty cycle too long 5. Motor failure 6. Bypass poppet clogged	Pump only low viscosity fluids. Clean filter assembly. Remove pump and clear suction pipe, replace as needed. Duty cycle is 30 minutes ON and 30 minutes OFF. Ball bearings damaged. UL Listing requires specific treatment for motor replacement, contact factory. Remove bypass poppet and clean.

SPECIFICATIONS

APPLICATION:	Designed to safely transfer low viscosity petroleum fuels such as gasoline (up to 15% alcohol blends such as E15), diesel fuel (up to 20% biodiesel blends such as B20) and kerosene. Pump is designed for permanent mounting on vented storage tanks.	
PUMP HOUSING:	Cast Iron	
PERFORMANCE:	Pump Rate:	Up to 20 GPM (76 LPM)
	Duty Cycle:	30 min. ON, 30 min. OFF
	Suction Lift:	Up to 15 feet (4.6 meters)
OPERATING TEMPERATURE:	-20°F to +125°F (-29°C to +52°C)	
EXTREME TEMPERATURE SERIES OPERATING TEMPERATURE	Extreme Temperature Series (XTS) pumps are capable of operation down to -40°F. Any pump operation below -20°F has not been evaluated by UL.	
BYPASS PRESSURE	20 PSI	
ELECTRICAL SPECIFICATIONS:	Input:	12-volt DC
	Current Draw:	27 A
	Motor:	2350 RPM, 3/10 hp (220 watts)
	Motor Approval:	 Class 1, Division 1, Group D
	Motor Protection:	40 amp circuit breaker
	Cord:	18 ft., 12 gauge
	Fuse:	40 amp
MECHANICAL CONNECTION:	Bung	2 inch NPT
	Inlet:	1 inch NPT
	Outlet:	1 inch NPT
ACCESSORIES:	Hose Type:	Buna-N Electrically Conductive Discharge Hose
	Hose Size:	1 in. NPT x 1 in. x 18 ft. (5.5 m)
	Manual Nozzle:	1 in. NPT Diesel
	Automatic Nozzle:	1 in. NPT Diesel
WEIGHT:	PRO20-012PO 35.5 lbs. (16.1 kg)	

PARTS AND SERVICE

In order to preserve the UL Listing for the motor, do not attempt to service the motor. For products serviced outside the factory, the UL nameplate must be defaced to indicate that the equipment may no longer meet the requirements for UL Listing. This does not apply to products serviced outside the factory under the UL program for Rebuilt Motors for Use in Hazardous Locations.

For warranty consideration, parts, or other service information, please contact your local distributor. If you need further assistance, contact the Great Plains Industries Customer Service Department in Wichita, Kansas, during normal business hours. A toll-free number is provided for your convenience.

800-835-0113 or 316-686-7361

To obtain prompt, efficient service, always be prepared with the following information:

1. The model number of your pump.
2. The serial number or manufacturing date code of your pump. For the PRO20-012 series pumps, the date code is located on the motor nameplate.

3. Part descriptions and numbers.

Part information can be obtained from the Illustrated Parts Drawing.

For warranty work, always be prepared with your original sales slip or other evidence of purchase date.


Please contact Great Plains Industries before returning any parts. It may be possible to diagnose the trouble and identify needed parts in a telephone call. Great Plains Industries can also inform you of any special requirements you will need to follow for shipping fuel dispensing equipment.

CAUTION

Do not return the pump or parts without authority from the Customer Service Department. Due to strict government regulations, Great Plains Industries cannot accept parts unless they have been drained and cleaned.

SAVE THESE INSTRUCTIONS

ILLUSTRATED PARTS DRAWING



GPRO®

Item No.	Part No.	Description	No. Req'd.
1	110244-02	Adjustable Suction Pipe	1
2	906001-10	Manual Diesel Nozzle, 1" NPT.....	1
3	110188-02	Fuel Hose, 1" NPT x 1" x 18'	1
4	501010-01	Power Cord, 12GA, 18'	1
5	133086-1	Switch Actuator Assembly	1
6	144125-01	Switch Bracket	1
7	902006-55	Circuit Breaker Switch.....	1
8	904002-25	Screw, Truss HD Machine, #10-32 X ½"	1
9	904005-56	Screw, Machine #6-32 X ¾"	2
10	144102-01	Bypass Valve Cap	1
11	144103-02	Bypass Valve Spring.....	1
12	144104-01	Bypass Valve Poppet	1
13	144105-01	Bypass Valve Orifice Seal.....	1
14	144110-01	5-Vane Rotor	1
15	144111-01	Carbon Sliding Vane 1.50"	5
16	144112-01	Drive Key	1
17	144124-01	Terminal Box Cover	1
18	144126-01	Switch Box Cover.....	1
19	144127-01	Switch Bushing	1
20	144140-01	Inlet Screen	1
21	901002-50	O-Ring, -916, 1.171 ID X .116, NBR	1
22	901004-10	O-Ring, -143, 2.425 ID X .103, NBR	1
23	901004-12	O-Ring, -148, 2.737 ID X .103, NBR	1
24	901004-13	O-Ring, -156, 4.237 ID X .103, NBR	1
25	901004-26	O-Ring, -135, 1.925 ID X .103, NBR	1

Item No.	Part No.	Description	No. Req'd.
26	904002-23	SEMS, Screw & Washer Assembly.....	11
27	904007-15	Socket Head Cap Screw	4
28	904008-53	Washer, .416, .750 x .063, Aluminum	1
29	904008-54	Retaining Ring, 10mm	1
30	904008-57	Screw, HSHC, ¼-20 X 1 ½"	4
31	906010-01	Shaft Seal, 10mm, NBR	1
32	144129-01	Switch Lever.....	1
33	144132-01	Closed Nozzle Cover.....	1
34	904006-62	Lock Nut, .375-16.....	1
35	904006-86	Tapping Screw.....	2
36	904008-52	Wave Overlap Spring.....	1
37	902005-91	Strain Relief	1
38	904004-43	Street Elbow, 1" NPT.....	1
39	906008-570	Automatic Diesel Nozzle, 1" NPT, UL.....	1
	133242-1	Nozzle Hook Only	1
	904001-88	Set Screw Only.....	2

Kits and Accessories

501500-03	Vane Kit, O-Ring, Vanes, Shaft Key
501500-04	Shaft Seal Kit, Retaining Ring, Shaft Seal, Spacer Washer
150100-502	Fuel Hose, Extreme Temperature Series, 1" NPT x 1" x 18'
906009-505	Automatic Diesel Nozzle, Extreme Temperature Series, 1" NPT, UL



M-3020 Motor for
Hazardous Locations

Wichita / Sydney / Mexico City



© 2017 Great Plains Industries, Inc., All Rights Reserved.
Great Plains Industries, Inc. / 800-835-0113 / GPI.net