


AVerMedia D331

Applies to NVIDIA Jetson T5000™/Jetson T4000™



AVerMedia Technologies, Inc.

No. 135, Jian 1st Rd., Zhonghe Dist., New Taipei City 23585, Taiwan

Tel: 886-2-2226-3630

Fax: 886-2-3234-4842

Sales and Marketing: [Contact](#)

Technical Support: [Professional User](#)

Table of Contents

Preface	4
Disclaimer	4
Technical Support	4
Contact Enquiry	4
Download User Manual	4
Revision History	5
https://www.avermedia.com/professional/contact	6
Product Warranty	7
Copyright Notice	7
Trademark Acknowledgement	8
ESD Warning	8
Safety Precaution:	9
1.0 Introduction	10
1.1 Product Specifications	11
1.2 Product Overview	12
1.3 Connector Summary	15
1.4 Carrier Board Interface	16
2.0 Feature Description	18
2.1 Jetson module Connector	18
2.2 Fan Power connector	18
2.3 RTC Battery Connector	19
2.4 HDMI OUTPUT	19
2.5 USB 3.2 Gen2 Type C Connector (supports Nvidia Jetson flashing)	19
2.6 USB Type C Power Supply Connector	20

2.7 USB 2.0 Type C Connector (Debug UART)	20
2.8 M.2 E key 2230	20
2.9 M.2 M key 2280	21
2.10 M.2 B key 3042/3052	21
2.11 Mini card socket	21
2.12 Gigabit Ethernet Connector	22
2.15 Micro SIM Card Slot	23
2.16 2x10 Euro Terminal Block 1x CAN-FD	23
2.17 2x10pin expansion header-1	24
2.18 2x10pin expansion header-2	25
2.19 Terminal block 3Pin	26
2.20 Output Power – 4.2mm Pitch ATX Power 4P	27
2.21 Input Power – 4.2mm Pitch ATX Power 6P	27
2.22 Board to board connector (to Camera board)	28
2.23 40pin coaxial connector	28
2.24 OOB Board Connector #1 (for optional OOB board)	29
2.25 OOB Board Connector #2 (for optional OOB board)	30
2.26 OOB board connector (Power)	31
2.27 Switch Button	31
2.28 Switch Button	33
2.29 Power & Recovery Button	33
2.30 3.5 mm audio jack	33
2.31 5-pin 12V DC wafer header	34
2.32 10-pin JTAG Header	35
3.0 Installation	36
3.1 BSP Setup Instructions	36

4.0

Software

37

5.0

Force Recovery Mode

39

6.0

Accessory Drawings

40

6.1

Power Cord

40

7.0

Daughter board introduction

43

7.1

D331 + ERMi Module

43

7.2

D331 + USB Daughter Board

44

7.3

D331 + GMSL Daughter Board

45

7.4

D331 + POE Daughter Board (TBD)

45

7.5

F1R4D Daughter Board

47

Preface

Disclaimer

The information contained in this user manual, including but not limited to any product specification, is subject to change without notice. AVerMedia assumes no liability for any damage incurred directly or indirectly from any technical or typographical errors or omissions contained herein or for discrepancies between the product and the user manual.

Technical Support

If you experience the difficulty after reading this manual and/or using the product, please contact the reseller from which you purchased the product. In most cases, the reseller can help you with the product installation and the difficulty you encountered.

In case the reseller is not able to resolve your problem, our highly capable global technical support team can certainly assist you. Our technical support section is available 24 hours a day and 7 days a week through our website, with the [click here](#). For more contact information, you may find it in the section of AVerMedia Global Offices.

Contact Enquiry

For more information of our products, pricing, and order placement, please fill in our inquiry form [here](#), we will contact you within 24 hours.

Download User Manual

Please click the link [here](#) to download the file of this user manual from AVerMedia website.

Revision History

Revision	Date	Updates
V0.1	Jan 29, 2026	1st Released
V0.2	Feb 2, 2026	Remove Fan Module Power Adapter Power Cord wrong information
V1.0	Feb 13, 2026	Update 2.0 Feature Description 9.0 Daughter board introduction
V1.1	Feb 23, 2026	Error Fix Add OOB demo connection
V1.2	Mar 3, 2026	Error Fix Add 2.17 2.18 pinout/pin definition
V1.3	Mar 5, 2026	Error Fix
V1.4	Mar 25, 2026	Product spec change 2.6 USB Type C Power Supply Connector
V1.5	Mar 26, 2026	Error Fix
V1.6	Apr 21, 2026	Error Fix
V1.7	May 12, 2026	Error Fix P.11~P.12
V1.8	May 27, 2026	Updated SSD Storage Spec Gen5 → Gen4
V1.9	June 22, 2026	Updated as D331 B version
V2.0	July 6, 2026	Updated P.26 Table
V2.1	Aug 18, 2026	Updated Specification.
V2.2	Aug 20, 2026	Updated J38

AVerMedia Global Offices

<https://www.avermedia.com/professional/contact>

Headquarters

Taiwan Office

No. 135, Jian 1st Rd., Zhonghe Dist., New
Taipei City 23585, Taiwan

Tel:  +886-2-2226-3630

Fax: +886-2-3234-4842

Sales & Marketing: [Contact](#)

Technical Support: [Home users](#) /

[Professional users](#)

The Americas

USA Office

4038 Clipper Court Fremont, CA 94538

Tel:  (510) 403-0006

Fax: (510) 403-0022

Sales & Marketing: [Contact](#)

Technical Support: [Home users](#) /

[Professional users](#)

Brazil Office

Sales & Marketing: [Contact](#)

Technical Support: [Home users](#) /

[Professional users](#)

Latin America Office

Sales & Marketing: [Contact](#)

Technical Support: [Home users](#) /

[Professional users](#)

Europe

Head Office EU

AVT Solutions GmbH

Hanauer Landstrasse 291 B 60314
Frankfurt Hessen

Germany

: technicalsupport_120

Sales & Marketing: [Contact](#)

Technical Support: [Home users](#) /

[Professional users](#)

Russia Office

Sales & Marketing: [Contact](#)

Technical Support: [Home users](#) /

[Professional users](#)

Professional Solutions Support Tel:

 +7 (925) 834-0310

Spain Office

AVerMedia Europe Group

Ronda de Poniente no. 4 segundo H

28760 Tres cantos, Madrid

Spain:

: technicalsupport_120

Sales & Marketing: [Contact](#)

Technical Support: [Home users](#) /

[Professional users](#)

Asia-Pacific

China Office

Room 1510, No.488, Hitech Plaza, South
Wuning Rd., Jingan District, Shanghai,
China

Tel:  +86-021-5298 7985

Fax: +86-021-5298 7981

Sales & Marketing: [Contact](#)

Technical Support: [Home users](#) /

[Professional users](#)

Japan Office

6F, Kojimachi Syuei Bldg. 4-3-13 Kudan-
minami, Chiyoda-ku, Tokyo, 102-0074,
Japan

Sales & Marketing: [Contact](#)

Technical Support: [Home users](#) /

[Professional users](#)

Product Warranty

Please refer to [Support | Warranty And Rma Services | AVerMedia](#)

Copyright Notice

The information contained in this document is subject to change without notice. AVerMedia shall not be liable for errors contained herein or for incidental consequential damages in connection with the furnishing, performance, or use of this material. This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent by AVerMedia.

Trademark Acknowledgement

AVerMedia acknowledges all the trademarks, registered trademarks, and/or copyrights referred to in this document as the property of their respective owners. Not listing all possible trademarks or copyright acknowledgments does not constitute the lack of acknowledgment to the rightful owners of the trademarks and copyrights mentioned in this document.

ESD Warning

Electronic components and circuits are sensitive to Electrostatic Discharge (ESD). When handling any circuit board assemblies including AVerMedia products, it is highly recommended that ESD safety precautions can be observed. ESD safe best practices can include but are not limited to the following ones.

1. Leave the circuit board in the antistatic package until it is ready to be installed.
2. Use a grounded wrist strap when handling the circuit board. At a minimum, you need to touch a grounded metal object to dissipate any static charge, which may be present on you.
3. Avoid handling the circuit board in the carpeted areas.
4. Handle the board by the edges and avoid contact with the components.
5. Only handle the circuit boards in ESD safe areas, which may include ESD floor and/or table mats, wrist strap stations, and ESD safe lab coats.

Safety Precaution:

1. All cautions and warnings on the device should be noted.
2. For safety consideration, do NOT open the device if not a qualified service staff.
3. Place the device on a solid surface during installation to prevent falls.
4. Keep the device away from humidity.
5. Do NOT leave this device in an un-controlled environment with temperatures beyond the device's permitted storage temperature to avoid damage.
6. All adaptors and cables supplied by AVerMedia are verified. Do NOT use any others not supplied by AVerMedia to avoid any malfunction or fires.
7. Make sure the power source matches the power rating of the device.
8. Place the power cord where people cannot step on it. Do not put anything on the power cord.
9. Always completely disconnect the power while the device is not used or idle for a long time.
10. Disconnect the device from any AC supply before cleaning. While cleaning, use damp cloth instead of liquid or spray detergents.
11. Make sure the device is installed near a power outlet and easy for accessibility.
12. Do not cover the openings on the device to ensure optimal heat dissipation.
13. Watch out the heatsink or heat spreader of the device when the system is running.
14. Never pour any liquid into the openings. This could cause fire or electrical shock.
15. The static electricity should be noted while installing any internal components. Consider using a grounding wrist strap and put all electronic parts in static-shielded containers.

If the following situations occur, please contact our service personnel:

- (1) The device is dropped or damaged
 - (2) Damaged power cord or plug
 - (3) Exposure to moisture
 - (4) Liquid intrusion into the device
 - (5) Any obvious signs of damage displayed on the device
 - (6) The device is not working as expected or in a manner as described in this manual
16. The static electricity should be noted while installing any internal components. Consider to

1.0 Introduction

AVerMedia D331 is a high-performance carrier board designed to support the NVIDIA® Jetson Thor™ module industry platform. Built with a comprehensive set of I/O interfaces including dual GbE, QSFP for high-speed networking, multiple M.2 expansion slots, rich peripheral connectivity, and robust industrial-grade design, the D331 enables rapid development and deployment of AI-driven embedded IoT solutions.


Equipped with a powerful NVIDIA Jetson T5000™/T4000™ system-on-module and a wide range of connectivity options such as HDMI, USB 3.2, CAN bus, PWM, and camera interfaces, the D331 carrier board delivers a flexible and scalable platform for demanding applications in autonomous mobile robotics (AMRs), smart security, smart inspection, and other edge computing use cases.

1.1 Product Specifications


NVIDIA Jetson SoM	NVIDIA Jetson T5000™/Jetson T4000™
Networking	• 2x GbE RJ-45 (1 × port supports OOB NCSI for optional OOB module) • 1x QSFP (4× 10 GbE) • 1x M.2. key E 2230 for Wi-Fi 6 • 1x M.2 Key B 3042/3052 for 4G/5G
SIM Slot	• 2x SIM slots for 4G/5G module; dual SIM capability depends on the installed cellular module
Display Output	2 x HDMI output (3840 x 2160 at 60Hz)
Temperature	Operating temperature: -40 to 85°C (carrier board, W/O audio) Operating temperature: -25 to 85°C (carrier board, W/ audio) Operating temperature: -25 to 60°C (Box PC) Operating temperature: -25 to 50°C (Box PC with 8x POE Board) Storage temperature -40°C ~ 85°C Relative humidity 40 °C @ 95%, Non-Condensing
GMSL camera board	1x 120pin for GMSL camera board
USB	• 1x USB 3.2 Type-C for BSP install • 1x USB 3.2 Type-C (usage limitations apply; refer to User Manual for details) • 4x USB 3.2 Type-A (5Gbps x2 ; 10Gbps x2) • Optional 8x USB3.2 Type-A (via daughter board)
Storage	• 2x NVMe M.2 Key M 2280 -1x NVMe M.2 Key M 2280 x2 PCIe Gen4 (For Carrier Board SKU: 8xPoE, 8xUSB board, either one) -1x NVMe M.2 Key M 2280 x4 PCIe Gen4
Expansion Header	• 2x10 Euro Terminal Block 1x CAN-FD (Isolated 3KV), 3x CAN-FD with Transceiver, +5V output 1A, +3.3V output 1A,UART, I2C • 20pin expansion header-1: 1x5V(Maximum 1A), 1x3.3V(Maximum 1A) power Output, UARTH1, I2C, GPO(4), GPI(5), PWM(2) • 20pin expansion header-2: 1x5V(Maximum 1A), 1x3.3V(Maximum 1A) power Output, UARTH2, I2C, GPO(4), GPI(5), PWM(2) • 2x 5-pin JTAG connector • 1x 40pin coaxial connector for PCIe expansion (For Carrier Board SKU: Daughter board 8xPSE/8xUSB)
Power requirement	• Terminal block 3Pin & Mini-fit 6pin (Internal) • USB Type C Power Supply • 9~36V (Max rating) DC Input • ACC IN / IGN Control (ACC optional, via switch)
Thermal Solution	• 1x SOM FAN • 2x Chassis Fan (12V fan wafer)

Buttons	Power and Recovery
RTC Battery	Support RTC Battery and Battery Life Monitoring by MCU
Dimensions	Carrier Board: W: 190mm x L: 190mm Devkit: W: 192.2mm x L: 195mm x H: 87mm Box PC: W: 211mm x L: 194mm x H: 115mm
Certifications	CE, FCC, VCCI, KC (TBA)
GPS	1x mPCIe for Optional Dual-RTK GNSS support (via daughter board)
Sensor	Temperature sensor for PCB top/bot Temperature measure
LED	1x system power , 1x input power
MISC	• 1x Mini-fit 4Pin DC output for PSE expansion (Pass-through 10A) • 1x DC output wafer (9~12V) for GMSL • 1x USB-C for Debug_UART (Share with OOB) • DIP Switch for function control , AT/ATX Mode select, ACC Enable / Ignore ACC for Development (default)
Package	1x Carrier board or Devkit or Box PC 1x 240W Adapter (360W with 8x POE Board) 1x Power Cord (By region) 2x Terminal Block

1.2 Product Overview



Front View and Back View of Carrier board




1.3 Connector Summary

J1	699-pin high-speed/high-density connector
J16	Fan Wafer
J3	External RTC Battery wafer
J18	HDMI output Type-A Vertical Side Connector (Female)
J19	HDMI output Type-A Vertical Side Connector (Female)
J31	USB 3.2 Gen2 Type C Connector (supports Nvidia Jetson flashing)
J30	USB Type C Power Supply Connector
J17	USB 2.0 Type C Connector (Debug UART)
J4	Gigabit Ethernet Connector w/LEDs
J10	Micro SIM card socket (Push-Push)
J21	2x10 Euro Terminal Block 1x CAN-FD
J22	20pin expansion header-1
J23	20pin expansion header-2
J29	QSFP
J32	Input Power – 4.2mm Pitch ATX Power 6P
J33	Input Power – Terminal block 3Pin
J34	Input Power – 4.2mm Pitch ATX Power 4P
J35	3.5mm audio Jack
J2	5 pin JTAG Header
J24	OOB board connector (Power)
J25	OOB board connector (Reset)
J26	OOB board connector (Recover)
BSW1	Recovery Button w/LEDs
BSW3	Power Button w/LEDs
J36	M.2 M-Key Socket
J8	USB 3.2 Gen2 Type A Connector
J7	M.2 E-Key Socket
J9	M.2 B-Key Socket
J6	Mini card socket
J27	OOB connector
J5	OOB NCSI connector
J14	4-pin USB wafer


J38	5-pin 12V DC output wafer
J39	M.2 M-Key Socket
J20	120-pin high speed board to board connector (to Camera board)
J12	40-pin coaxial connector
JP1	Fan Wafer
JP2	Fan Wafer
SW7	Switch Button
SW8	Switch Button
SW9	Switch Button

1.4 Carrier Board Interface

Top View Interface



Bottom iew Interface



2.0 Feature Description

2.1 Jetson module Connector

Function	Provide connection with NVIDIA® Jetson™ AGX Thor™ module	
Location	J1	
Type Description	MOLEX 699pin socket	
Manufacturer and Part Number	MOLEX,203456-0003	
Mating Connector	MOLEX,203456-0003	
Pinout	Please refer to NVIDIA Jetson™ AGX Thor™ System-on-Module datasheet for pinout details.	
Remarks	https://developer.nvidia.com/embedded/downloads	

2.2 Fan Power connector

Function	Fan Power Connector			
Location	J16 / JP1 / JP2			
Type Description	WAFER_1*4PIN_2 mm_90°_SMD			
Manufacturer and Part Number	JOINT TECH 燦達 A2001WR-S-04PNLNT1T00R			
Mating Connector	JOINT TECH 燦達 A2001 Series Housing			
Pinout	Pin #	Description		
	PIN 1	GND		
	PIN 2	+12V Power		
	PIN 3	FAN_TACH		
	PIN 4	FAN_PWM		
Remarks	None			


2.3 RTC Battery Connector

J3 - RTC Battery Connector				
Function	RTC battery for module			
Location	J3			
Type Description	1.25mm wire-to-board header			
Manufacturer and Part Number	宏致_ACES 50271-00201-001_BLACK			
Mating Connector	Molex, 51021-8602			
Pinout	Pin #	Description		
	PIN1	GND		
	PIN2	3V Power		
Remarks	RTC Battery:., CR2032 3V			



2.4 HDMI OUTPUT

Function	HDMI output connector		
Location	J19/J18		
Type Description	HDMI Type-A female connector		
Manufacturer and Part Number	捷湧 EDL TECHNOLOGY CO. HM-FVD480B		
Mating Connector	Any HDMI standard Type-A interface cable or device.		
Pinout	Please refer to HDMI standard.		
Remarks	None		



2.5 USB 3.2 Gen2 Type C Connector (supports Nvidia Jetson flashing)

Function	BSP Installation as recovery mode		
Location	J31		
Type Description	USB3.2 Type-C female connector		
Manufacturer and Part Number	GM9-HF JACK_建倚_SBC-240P- 31HF-S277_-55+85°C		
Mating Connector	Any Standard Type-C interface cable or device.		
Pinout	Please refer to USB 3.2 Gen 2 standard.		
Remarks	J31 supports Nvidia Jetson flashing		



2.6 USB Type C Power Supply Connector

No. USB Type-C Power Supply Connector		
Function	USB Type -C power supply	
Location	J30	
Type Description	USB3.1 Type-C female connector	
Manufacturer and Part Number	GM9-HF JACK_建倚_SBC-240P-31HF-S277_-55+85°C	
Mating Connector	Any Standard Type-C interface cable or device.	
Pinout	Please refer to USB 3.1 type- C standard	
Remarks	NONE	


2.7 USB 2.0 Type C Connector (Debug UART)

Function	For dumping debug UART	
Location	J17	
Type Description	USB2 .0 Type-C female connector	
Manufacturer and Part Number	GM9-HF_JACK_建倚_SBC-240P-31HF-S277_-55+85°C	
Mating Connector	Any Standard Type-C interface cable or device.	
Pinout	Please refer to USB 2.0 standard.	
Remarks	None	

2.8 M.2 E key 2230

Function	M.2 E-Key for wifi module	
Location	J7	
Type Description	SOCKET_M.2-KEY E_75PIN 90°_SMD	
Manufacturer and Part Number	宏致_ACES 51748-07502-005_P0.5 mm-H8.5 mm	
Mating Connector	Any M.2 E key 2230 card standard interface device.	
Pinout	Please refer to M.2 E key card standard for the pinout details.	
Remarks	None	

2.9 M.2 M key 2280

Function	M.2 M-Key	
Location	J36/J39	
Type Description	SOCKET_M.2-M KEY _75PIN _90°_SMD	
Manufacturer and Part Number	宏致_ACES 51757-0750C-012_P0.5 mm-H5.5 mm	
Mating Connector	Any M.2 M key 2280 card standard interface device.	
Pinout	Please refer to M.2 M key card standard for the pinout details.	
Remarks	J39 only support PCIe 2-Lane	

2.10 M.2 B key 3042/3052

Function	M.2 B-Key for 4G/5G module	
Location	J9	
Type Description	SOCKET_M.2-KEY B_75PIN_90°_SMD	
Manufacturer and Part Number	鴻海_Foxconn 2E0BC21-S85BB-7H_90°_H8.5 mm	
Mating Connector	Any M.2 B key 2280 card standard interface device.	
Pinout	Please refer to M.2 B key card standard for the pinout details.	
Remarks	None	

2.11 Mini card socket

Function	Mini Card (PCIe) interface	
Location	J6	
Type Description	SOCKET_MINI PCIE_52PIN	
Manufacturer and Part Number	FOXCONN, AS0B221-S68Q 7H_H=6.8MM-062AL6	
Mating Connector	Any Mini Card standard interface device.	
Pinout	Please refer to Mini Card standard for the pinout details.	
Remarks	None	

2.12 Gigabit Ethernet Connector

Function	1Gb single-port Ethernet connector, used to connect to the host system.	
Location	J4	
Type Description	JACK_RJ45*2_TRANSFOMER+LED_90°_DIP	
Manufacturer and Part Number	鉉運_JDKA1S826-G/D1_1G-LED L(G)+R(G/Y)	
Mating Connector	Any standard 1Gb Ethernet mating connector can be applicable.	
Pinout	Comply with Ethernet standards.	
Remarks	None	

2.13 QSFP Connector

Function	QSFP Connector	
Location	J29	
Type Description	OTHERS_CAGE_20.99*61.17 mm _QSFP28-STYLE A	
Manufacturer and Part Number	GM9_OTHERS_湧德_PRESS FIT-90°-W/O LED & HEATSINK	
Mating Connector	Any standard QSFP mating connector can be applicable	
Pinout	N/A	
Remarks	None	


2.14 USB 3.2 Gen2 Type A Connector

Function	General-purpose input/output	
Location	J8	
Type Description	USB 3.2 Gen2 Type A female connector	
Manufacturer and Part Number	GM9-HF_JACK_鴻海_UEA11123-QHD6-4H_-55+85°C	
Mating Connector	Any Standard Type-A interface cable or device.	
Pinout	Please refer to USB 3.2 standard.	
Note	None	

2.15 Micro SIM Card Slot

Function	Micro SIM Card	
Location	J10	
Type Description	SOCKET_MICRO SIM_8PIN_90°_SMD	
Manufacturer and Part Number	福軒_FG-0271AAAG06A_PUSH PUSH 1.42H	
Pinout	Refer to Micro SIM card standard Remark	
Note	*Push Push type *Inserting directing as below	


2.16 2x10 Euro Terminal Block 1x CAN-FD

Function	General-purpose input/output					
Location	J21					
Type Description	Expansion I/O Connector					
Manufacturer and Part Number	ME252-35020-1					
Mating Connector	2x10 Euro Terminal Block 1x CAN-FD					
Pinout	Address JP7	Pin Name	20-pin Index (Devkit Index)		Pin Name	Address JP7
		5V	A1	B1	3V3	
		GND	A2	B2	GND	
	/dev/ttyAMA5	UART5_TX_3V3 J58(UF3_TXD)	A3	B3	I2C_GP8_DAT_3V3 (E60)	i2c-3
	/dev/ttyAMA5	UART5_RX_3V3 H58(UF3_RXD)	A4	B4	I2C_GP8_CLK_3V3 (D61)	i2c-3
		ISO_GND	A5	B5	GND	
		CANL0_ISO	A6	B6	CANL2	
		CANH0_ISO	A7	B7	CANH2	
		GND	A8	B8	CANL3	
		CANL1	A9	B9	CANH3	
		CANH1	A10	B10	GND	
	Note	None				

2.17 2x10pin expansion header-1


Function	General-purpose input/output					
Location	J22					
Type Description	WAFER_2*10PIN_1 mm_180°_SMD					
Manufacturer and Part Number	GM2_WAFER_JST_BM20B-SHLDS-G-TFT(LF)(SN)					
Mating Connector	Any Standard interface cable or device.					
Pinout	Address JP7	Pin Name	20-pin Index (Devkit Index)		Pin Name	Address JP7
		3V3	1	2	5V	
		GND	3	4	GND	
	i2c-9	I2C_GPY_DAT_3V3 (CS3)	5	6	UART1_TX_3V3 (GL3590 未動作)	
	i2c-9	I2C_GPY_CLK_3V3 (AS3)	7	8	UART1_RX_3V3 (GL3590 未動作)	
	chip 2 gpio 127	GPIO027_P002_3V3 PF.07 J22.9, PWM	9	10	GND	
	chip 2 gpio 16	I2S1_LBCK_P0010_3V3 GPIO03_PV.01 (devkit Usage: SP10 3V3_OP_IN) J22.11, PWM	11	12	SP11_SCK_3V3 GPIO03_PJ.07 J22.12, GP1	chip 2 gpio 71
	chip 2 gpio 112	I2S1_SCLK_3V3 GPIO03_PK.02 J22.13, GPO High	13	14	SP11_MISO_3V3 GPIO03_PK.00 J22.14 GP1	chip 2 gpio 72
	chip 2 gpio 113	I2S1_SDOOUT_3V3 GPIO03_PK.03 J22.15, GPO High	15	16	SP11_MOSI_3V3 GPIO03_PK.01 J22.16, GP1	chip 2 gpio 73
	chip 2 gpio 114	I2S1_SDIN_3V3 GPIO03_PK.04 J22.17, GPO High	17	18	SP11_CS0_3V3 GPIO03_PK.02 J22.18, GP1	chip 2 gpio 74
	chip 2 gpio 115	I2S1_LBCK_3V3 GPIO03_PK.05 J22.19, GPO High	19	20	SP11_CS1_3V3 GPIO03_PK.03 J22.20, GP1	chip 2 gpio 75

Remarks	
---------	--




2.18 2x10pin expansion header-2

Function	General-purpose input/output					
Location	J23					
Type Description	WAFER_2*10PIN_1 mm_180°_SMD					
Manufacturer and Part Number	GM2_WAFER_JST_BM20B-SHLDS-G-TFT(LF)(SN)					
Mating Connector	Any Standard interface cable or device.					
Pinout	Address JP7	Pin Name	20-pin Index (Devkit Index)		Pin Name	Address JP7
		3V3	1	2	5V	
		GND	3	4	GND	
	i2c-11	I2C_GP11_DAT_3V3 (E26)	5	6	UARTH2_TX_3V3	/dev/ttyUSB0
	i2c-11	I2C_GP11_CLK_3V3 (E27)	7	8	UARTH2_RX_3V3	/dev/ttyUSB0
	chip 2 gpio 128	GP1036_PWM3_3V3 PG.00 J23.9, PWM	9	10	GND	
	chip 2 gpio 14	GP1044_PWM5_3V3 PU.07 J23.11, PWM	11	12	SP13_SCK_3V3 GP103_PU.06 J23.12, GP1	chip 2 gpio 62
	chip 2 gpio 21	I2S2_SCLK_3V3 GP103_PV.06 J23.13, GPO High	13	14	SP13_MISO_3V3 GP103_PU.07 J23.14 GP1	chip 2 gpio 63
	chip 2 gpio 22	I2S2_SDOOT_3V3 GP103_PV.07 J23.15, GPO High	15	16	SP13_MOSI_3V3 GP103_PJ.00 J23.16, GP1	chip 2 gpio 64
	chip 2 gpio 23	I2S2_SDIN_3V3 GP103_PW.00 J23.17, GPO High	17	18	SP13_CS0_3V3 GP103_PJ.01 J23.18, GP1	chip 2 gpio 65
	chip 2 gpio 24	I2S2_LRCK_3V3 GP103_PW.01 J23.19, GPO High	19	20	SP13_CSI_3V3 GP103_PJ.02 J23.20, GP1	chip 2 gpio 66




Remarks	
---------	--




2.19 Terminal block 3Pin

Function	DC power input		 							
Location	J33									
Type	SOCKET_TERMINAL									
Description	BLOCK_1*3PIN_90°_DIP									
Manufacturer and Part Number	GM9_SOCKET_進聯_ME050-50803_GREEN-P5.08 mm-PIN L4.5 mm									
Mating Connector	QSFP Connector									
Pinout	<table><tr><th>Pin Number</th><th>Description</th></tr><tr><td>1</td><td>ACC</td></tr><tr><td>2</td><td>GND</td></tr><tr><td>3</td><td>DC IN</td></tr></table>			Pin Number	Description	1	ACC	2	GND	3
Pin Number	Description									
1	ACC									
2	GND									
3	DC IN									
Remarks	None									

2.20 Output Power – 4.2mm Pitch ATX Power 4P

Function	ATX 4P											
Location	J34											
Type Description	WAFER_2*2PIN_4.2 mm_DIP											
Manufacturer and Part Number	福軒 Fullglory FPWD-42R2-04NAT											
Mating Connector	Follow ATX 4pin power standard											
Pinout	<table><tr><th>Pin Number</th><th>Description</th></tr><tr><td>1</td><td>GND</td></tr><tr><td>2</td><td>GND</td></tr><tr><td>3</td><td>9-36V Power</td></tr><tr><td>4</td><td>9-36V Power</td></tr></table>			Pin Number	Description	1	GND	2	GND	3	9-36V Power	4
Pin Number	Description											
1	GND											
2	GND											
3	9-36V Power											
4	9-36V Power											
Remarks	None											

2.21 Input Power – 4.2mm Pitch ATX Power 6P

Function	DC power input		
Location	J32		
Type Description	WAFER_2*3PIN_4.2 mm_180°_DIP-L3.5 mm		
Manufacturer and Part Number	GM1-HF_WAFER_宏致_56973-0060N-001_ATX POWER-NATURAL		
Mating Connector	Follow ATX 6pin power standard		
Pinout	Pin Number	Description	
	1	12-54V Power	
	2	12-54V Power	
	3	ACC	
	4	GND	
	5	GND	
	6	GND	
Remarks	None		

2.22 Board to board connector (to Camera board)

J20 Board to board connector (to Camera Board)		
Function	Board to board connector	
Location	J20	
Type Description	WAFER 2*60PIN 0.5 mm 180° SMD	
Manufacturer and Part Number	SAMTEC QSH-060-01-L-D-A-K-TR BTB-RECEPTACLE	
Mating Connector	SAMTEC QTH-060-03-H-A-D BTB-PLUG QTH-060-04-H-A-D BTB-PLUG	
Pinout	Comply with NVIDIA Devkit pinout.	
Remarks	None	

2.23 40pin coaxial connector

Function	40pin coaxial connector for	
----------	-----------------------------	--

	daughter board	
Location	J12	
Type Description	WAFER_40PIN_0.5 mm 90° SMD	
Manufacturer and Part Number	I-PEX 20455-040E-12	
Mating Connector	I-PEX 20453-240T-03	
Pinout	Any Standard coaxial connector interface cable or device.	
Remark	NA	

2.24 OOB Board Connector #1 (for optional OOB board)

Function	OOB Board Connector (for NC-SI)			
Location	J5			
Type	WAFER_1*10PIN_1 mm_180°_SMD			
Description				
Manufacturer and Part Number	ACES 50228-01071-001			
Mating Connector	ACES 50233-010H0H0-001			
Pinout	PIN#	Description	Module Pin#	Type/ Dir
	1	NC SI TXD0		Input, 3.3V
	2	NC SI TXD1		Input, 3.3V
	3	NC SI TX EN		Input, 3.3V
	4	GND		Ground
	5	NC SI CLK IN		Input, 3.3V
	6	GND		Ground
	7	NC SI RXD0		Output, 3.3V
	8	NC SI RXD1		Output, 3.3V
	9	N C SI CRS DV		Output, 3.3V
	10	GND		Ground


Remark	For optional OOB with NCSI board
--------	----------------------------------

2.25 OOB Board Connector #2 (for optional OOB board)

Function	OOB Board Connector(basic function)			
Location	J27			
Type Description	WAFER_1*10PIN_1 mm_180°_SMD			
Manufacturer and Part Number	ACES 50228-01071-001			
Mating Connector	ACES 50233-010H0H0-001			
Pinout	PIN#	Description	Module Pin#	Type/ Dir
	1	GND		Ground
	2			Input, 3.3V
	3	UART3_RX (Debug OOB)		Input, 3.3V
	4	UART3_TX (Debug OOB)		Ground
	5	UART1_RX 3V3		Input, 3.3V
	6	UART1_TX 3V3		Ground
	7	+5V SOM PG		Output, 3.3V
	8	RST OOB		Output, 3.3V
	9	POWER_BTN		Output, 3.3V
	10	+5V STANDBY		Ground
Remark	For optional OOB with NCSI board			

Pinout	SW7	
	Pin #	Description
	1	OFF=>CAN0 W/O Terminal ON=> CAN0 W Terminal
	2	OFF=>CAN1 W/O Terminal ON=> CAN1 W Terminal
	3	OFF=>CAN2 W/O Terminal ON=> CAN2 W Terminal
	4	OFF=>CAN3 W/O Terminal ON=> CAN3 W Terminal
	SW8	
	Pin #	Description
	1	OFF=>Auto Power ON=>Button Power
	2	OFF=>FAN PWM ON=>FAN Always
	3	OFF=>Always Powser ON Disable ON=> Always Powser ON Enable
	4	OFF=>Ignore ACC for Development ON=> ACC Enable
Remark	NA	

2.28 Switch Button

Function	Switch Button	
Location	SW9	
Type Description	SW_DIP_NDSVM-02Q-T-R_SMD4	
Manufacturer and Part Number	GM1-HF_SWITCH_冠泰_IN OFF-SWITCHING 0.025A/24VDC	
Pinout		
Remark	None	

2.29 Power & Recovery Button

12VDC Power & Recovery Button		
Function	Power & Recovery control button	
Location	BSW1, BSW3	
Type Description	Button	
Manufacturer and Part Number	冠泰 Champway 12VDC/0.05A-160G-H1.8 mm-BLACK	
Pinout	N/A	
Remark	None	

2.30 3.5 mm audio jack

Function	MIC in / Headphone output	
Location	J35	
Type Description	JACK_PHONE*2_D3.5-BLACK_90°_DIP	
Manufacturer and Part Number	GM1_JACK_京政_PJD-035-87HAB	
Top : MIC in	Top : MIC in	

Button :	Button : Headphone out
Headphone out	
Remark	None

2.31 5-pin 12V DC wafer header

Function	5-pin 12V DC	
Location	J38	
Type Description	WAFER_1*5PIN_2 mm_180°_SMD	
Manufacturer and Part Number	宏致_50310-0057N-001_WTB HEADER-H6.5 mm	
Pinout		
Remark	None	



1 2 3 4 5



1 2 3 4 5

2.32 10-pin JTAG Header

Function	JTAG																										
Location	J2																										
Type Description	HEADER_PIN_2*5PIN_1.27 mm _180°_SMD																										
Manufacturer and Part Number	冠泰_PH13-10VM1002CU8-06																										
Pinout	<table border="1"> <thead> <tr> <th>Pin</th><th>Description</th><th>Pin</th><th>Description</th></tr> </thead> <tbody> <tr> <td>1</td><td>JTAG_TMS</td><td>2</td><td>+1.8V</td></tr> <tr> <td>3</td><td>JTAG_TCK</td><td>4</td><td>GND</td></tr> <tr> <td>5</td><td>JTAG_TDO</td><td>6</td><td>GND</td></tr> <tr> <td>7</td><td>JTAG_TDI</td><td>8</td><td>GND</td></tr> <tr> <td>9</td><td>RESET_IN</td><td>10</td><td>GND</td></tr> </tbody> </table>			Pin	Description	Pin	Description	1	JTAG_TMS	2	+1.8V	3	JTAG_TCK	4	GND	5	JTAG_TDO	6	GND	7	JTAG_TDI	8	GND	9	RESET_IN	10	GND
Pin	Description	Pin	Description																								
1	JTAG_TMS	2	+1.8V																								
3	JTAG_TCK	4	GND																								
5	JTAG_TDO	6	GND																								
7	JTAG_TDI	8	GND																								
9	RESET_IN	10	GND																								
Remark	None																										



Other Switches and Jumpers

Other switches and jumpers listed on the board but not mentioned in this manual are reserved for internal use by AVerMedia. They are not open to the client application.

3.0 Installation

- Check and ensure all external system power supplies are turned off.
- Connect the power cord to CB/devkit/Box PC DC in jack or ATX 4pin
- Connect the USB Type-C cable to CB/devkit/Box PC connector.
- Press and hold on the Recover button
- Plug in AC power

(Since the DCINJACK is slightly tight, be careful not to shake it when inserting the CB/devkit/Box PC)

3.1 BSP Setup Instructions

BSP (board support package) file: AVERMEDIA_JETPACK-R2.*.*.*_desktop.tar.gz for D331

If you want to get the BSP download link, please contact AVerMedia FAE.

Default login username/password of the BSP is nvidia/nvidia

If you have difficulties to access the BSP download link, please visit AVerMedia website at <https://www.avermedia.com/professional/download>, or contact technical support at https://www.avermedia.com/professional/technical_support or e-mail us at esusupport@avermedia.com for further assistance.

BSP Installation steps for NVIDIA Jetson board: (Important Note: Please backup your personal files before re-flashing BSP)

After you download the BSP file and put the file in a Linux PC, please refer to the steps below to re-flash BSP.

1. Let the JETSON AGX Thor initiate recovery mode.

You have to keep pressing “Recovery” button and then power on the NVIDIA Jetson board to initiate recovery mode.

When connecting a NVIDIA Jetson board to a Linux PC via a USB Type-C to USB cable, you can check kernel messages with ‘dmesg’ command in the Linux PC.

Once you see similar messages as below, it means that the NVIDIA Jetson board is in the recovery mode.

```
[24685.229129] usb 1-7: Product: APX
```

```
[24685.229132] usb 1-7: Manufacturer: NVIDIA Corp
```

2. Using the commands below in the Linux PC to start re-flashing BSP.

sudo is required to extract BSP

```
$ sudo tar zxvf AVERMEDIA_JETPACK- R2.*.*.*_desktop.tar.gz
```

```
$ cd JetPack_*.**_desktop/Linux_for_Tegra
```

\$ installation steps: refer to AVERMEDIA_JETPACK- R2.*.*.*_ReleaseNote.txt

4.0 Software

This section describes BSP's features for D331

1. Support optional M.2 WI-FI/Bluetooth modules (Intel® Wireless-AX210), the manager UI of AX210 WiFi/Bluetooth is located on the upper-right corner of Ubuntu desktop. It can be also controlled by nmcli/bluetoothctl in command line.
2. Power Mode
Power mode can be modified by the UI on the upper-right corner of Ubuntu or the following commands.

```
# get current power mode
$ sudo nvpmodel -q
# setup power mode
# where <x> is power mode number, please refer to
https://docs.nvidia.com/jetson/archives/r36.4.3/DeveloperGuide/SD/PlatformPowerAndPerformance/JetsonOrinNanoSeriesJetsonOrinNxSeriesAndJetsonAgxOrinSeries.html#supported-modes-and-power-efficiency for more
information
$ sudo nvpmodel -m <x>
```

RTC Battery

The following command can get RTC battery voltage.

```
$ sudo avt_tool -a | grep -oP "AIN5.*\[[K^\]]*"
```

3. Fan Speed

The following commands can get PWM fan information.

```
# get current speed setting of PWM Fan (0 ~ 255)
$ cat /sys/devices/platform/pwm-fan/hwmon/hwmon<x>/pwm1

# get Fan RPM value
```

```
$ cat /sys/class/hwmon/hwmon<y>/rpm
```

* Where <x> and <y> are dynamic hwmon indexes.

4. CAN Bus (removed to daughter board)

5. Camera (removed to daughter board)

6. GPIO usage

(1) Locate the GPIO Pin:

Use the `gpiofind` command to determine the pin's location in the system. For example,

to locate the SODIMM Pin 99, which corresponds to PX.04, execute:

```
$ sudo gpiofind PX.04
```

This command will return the GPIO chip and offset. For example, it might return `gpiochip0 118`, indicating that PX.04 is at offset 118 on `gpiochip0`

(2) Set the GPIO Pin Voltage:

Set High Voltage: To set the pin to a high voltage (logic level 1), use the following command:

```
$ sudo gpiowrite --mode=wait 0 118=1
```

Set Low Voltage: To set the pin to a low voltage (logic level 0), use this command:

```
$ sudo gpiowrite --mode=wait 0 118=0
```

For L4T (Linux for Tegra) BSP support and the other software support associated with NVIDIA® Jetson AGX Thor, please visit AVerMedia website to contact our technical support function. (<https://www.avermedia.com/tw/support/contact>)

5.0 Force Recovery Mode


USB Type-C port (J31) of D331 can be used to re-program NVIDIA® Jetson AGX Thor by using the other host system running NVIDIA Jetpack, as the procedure described below.

1. Before you start
 - Please make sure to use a Linux host PC with Ubuntu 22.04 or 20.04 operating system.
 - Please use a native setup (no virtual machine) installation file in the following steps.
 - You will also need a high-quality standard USB Type C connector.
 - Download installation file from AVermedia.
2. Connect carrier board to host PC
3. Connect the system to the Linux host PC. Please use a USB Type C cable (J31 on the carrier board).
4. After connecting to the host PC powering up the system. The system will detect the host PC and automatically enter the flashing state (also called force recovery mode).
5. Check that the connection is established with the `lsusb` command. You should find one entry with Nvidia Corp. as highlighted below.
6. Flashing of system
 - Use the flash cmd script in the extracted bootloader folder to transfer the software into the Jetson compute module and flash it.
 - Please connect a monitor to the system. After the flashing process has completed the should automatically boot and show the Ubuntu desktop.
 - You now have a functioning system ready for your needs.


6.0 Accessory Drawings

6.1 Power Cord


64APOWBRX-IPD (TW version)




064APOWBR2-IPD (US version)




064APOWBRW-IPD (UK version)



064APOWBR5-IPD (EU version)



Dd 064APOWBR4-IPD (CN version)




7.0 Daughter board introduction


7.1 D331 + ERMi Module

Please refer to [ERMi Module | Out-of-Band Management | AVerMedia](#)

OOB demo connection




NCSI OOB demo connection




7.2 D331 + USB Daughter Board

Please refer to [USB-board](#) | AVerMedia




On D331, The red end of the cable must be aligned with the resistor indicated by the yellow arrow and properly connected.

On USB Daughter Board, The red end of the cable must be aligned with the resistor indicated by the yellow arrow and properly connected.




(On D331)




(On USB Daughter Board)

7.3 D331 + GMSL Daughter Board

Please refer to GMSL Board | AVerMedia
Connect GMSL Daughter Board with J20




7.4 D331 + POE Daughter Board (TBD)




On D331, The red end of the cable must be aligned with the resistor indicated by the yellow arrow and properly connected.

On POE Daughter Board, The red end of the cable must be aligned with the resistor indicated by the yellow arrow and properly connected.





(On D331)




(On POE Daughter Board)

7.5 F1R4D Daughter Board

Function	Serial Port		 																				
Location	CN1																						
Type Description	JACK_D-SUB_9PIN(M)- BLACK_90°_DIP-L3.2 mm																						
Manufacturer and Part Number	光榮 DBMRx002-09																						
Mating Connector	N/A																						
Pinout	<table><tr><th>Pin #</th><th>Description</th></tr><tr><td>1</td><td>SPI1_CS1_GPI</td></tr><tr><td>2</td><td>SPI1_MOSI_GPI</td></tr><tr><td>3</td><td>I2S1_LRCK_GPO</td></tr><tr><td>4</td><td>I2S1_SDOUT_GPO</td></tr><tr><td>5</td><td>GND</td></tr><tr><td>6</td><td>SPI1_CS0_GPI</td></tr><tr><td>7</td><td>SPI1_MISO_GPI</td></tr><tr><td>8</td><td>I2S1_SDIN_GPO</td></tr><tr><td>9</td><td>I2S1_SCLK_GPO</td></tr></table>			Pin #	Description	1	SPI1_CS1_GPI	2	SPI1_MOSI_GPI	3	I2S1_LRCK_GPO	4	I2S1_SDOUT_GPO	5	GND	6	SPI1_CS0_GPI	7	SPI1_MISO_GPI	8	I2S1_SDIN_GPO	9	I2S1_SCLK_GPO
Pin #	Description																						
1	SPI1_CS1_GPI																						
2	SPI1_MOSI_GPI																						
3	I2S1_LRCK_GPO																						
4	I2S1_SDOUT_GPO																						
5	GND																						
6	SPI1_CS0_GPI																						
7	SPI1_MISO_GPI																						
8	I2S1_SDIN_GPO																						
9	I2S1_SCLK_GPO																						
Note																							

Function	DI/DO																				
Location	CN2																				
Type Description	JACK_D-SUB_9PIN(M)- BLACK_90°_DIP-L3.2 mm																				
Manufacturer and Part Number	光榮 DBMRx002-09																				
Mating Connector	N/A																				
Pinout	<table><thead><tr><th>Pin #</th><th>Description</th></tr></thead><tbody><tr><td>1</td><td>TX_N</td></tr><tr><td>2</td><td>TX_P</td></tr><tr><td>3</td><td>RX_P</td></tr><tr><td>4</td><td>RX_N</td></tr><tr><td>5</td><td>GND</td></tr><tr><td>6</td><td>NC</td></tr><tr><td>7</td><td>NC</td></tr><tr><td>8</td><td>NC</td></tr><tr><td>9</td><td>NC</td></tr></tbody></table> GND RS232 SOUTN RS232 SINN  RS232 RS485 TX+ (A) RS485 TX- (B)  RS485 RS422 RX- (B) RS422 RX+ (A) RS422 TX+ (A) RS422 TX- (B)  RS422	Pin #	Description	1	TX_N	2	TX_P	3	RX_P	4	RX_N	5	GND	6	NC	7	NC	8	NC	9	NC
Pin #	Description																				
1	TX_N																				
2	TX_P																				
3	RX_P																				
4	RX_N																				
5	GND																				
6	NC																				
7	NC																				
8	NC																				
9	NC																				
Note																					



Function	Pass-Through 20Pin for GPIOs																																															
Location	J1 & J2																																															
Type Description	WAFER_2*10PIN_1 mm_180°_SMD																																															
Manufacturer and Part Number	JST BM20B-SHLDS-G-TFT(LF)(SN)																																															
Mating Connector	N/A																																															
Pinout	<table><tr><th>Pin#</th><th>Description</th><th>Pin#</th><th>Description</th></tr><tr><td>1</td><td>+3V3_EXP2</td><td>2</td><td>+5V_EXP2</td></tr><tr><td>3</td><td>GND</td><td>4</td><td>GND</td></tr><tr><td>5</td><td>I2C_GP9_DAT_3V3</td><td>6</td><td>UARTH1_TX_3V3</td></tr><tr><td>7</td><td>I2C_GP9_CLK_3V3</td><td>8</td><td>UARTH1_RX_3V3</td></tr><tr><td>9</td><td>GPIO27_PWM2_3V3</td><td>10</td><td>GND</td></tr><tr><td>11</td><td>I2S7_LRCK_PWM10_3V3</td><td>12</td><td>SPI1_SCK_3V3</td></tr><tr><td>13</td><td>I2S1_SCLK_3V3</td><td>14</td><td>SPI1_MISO_3V3</td></tr><tr><td>15</td><td>I2S1_SDOOUT_3V3</td><td>16</td><td>SPI1_MOSI_3V3</td></tr><tr><td>17</td><td>I2S1_SDIN_3V3</td><td>18</td><td>SPI1_CS0_3V3</td></tr><tr><td>19</td><td>I2S1_LRCK_3V3</td><td>20</td><td>SPI1_CS1_3V3</td></tr></table>				Pin#	Description	Pin#	Description	1	+3V3_EXP2	2	+5V_EXP2	3	GND	4	GND	5	I2C_GP9_DAT_3V3	6	UARTH1_TX_3V3	7	I2C_GP9_CLK_3V3	8	UARTH1_RX_3V3	9	GPIO27_PWM2_3V3	10	GND	11	I2S7_LRCK_PWM10_3V3	12	SPI1_SCK_3V3	13	I2S1_SCLK_3V3	14	SPI1_MISO_3V3	15	I2S1_SDOOUT_3V3	16	SPI1_MOSI_3V3	17	I2S1_SDIN_3V3	18	SPI1_CS0_3V3	19	I2S1_LRCK_3V3	20	SPI1_CS1_3V3
	Pin#	Description	Pin#	Description																																												
	1	+3V3_EXP2	2	+5V_EXP2																																												
	3	GND	4	GND																																												
	5	I2C_GP9_DAT_3V3	6	UARTH1_TX_3V3																																												
	7	I2C_GP9_CLK_3V3	8	UARTH1_RX_3V3																																												
	9	GPIO27_PWM2_3V3	10	GND																																												
	11	I2S7_LRCK_PWM10_3V3	12	SPI1_SCK_3V3																																												
	13	I2S1_SCLK_3V3	14	SPI1_MISO_3V3																																												
	15	I2S1_SDOOUT_3V3	16	SPI1_MOSI_3V3																																												
	17	I2S1_SDIN_3V3	18	SPI1_CS0_3V3																																												
	19	I2S1_LRCK_3V3	20	SPI1_CS1_3V3																																												
Note																																																