# NEMESIS DELAY

## Quick Start Reference Card

### POWER

Power your Nemesis with the included power supply. If you're using a pedalboard power supply, be sure to use a regulated 9 Volt DC output that can source at least 200mA.

### CONTROLS

**TIME** - Sets delay time. Range varies per engine. Max 2.6 second delay.
**MIX** - Sets the wet/dry mix. The mid-point of the knob is a 50/50 mix.
**FEEDBACK** - Controls number of repeats. Use caution with high feedback!
**MOD/RATE** - Controls depth and speed of time/pitch modulation.
**TRAILS MODE** - Press+hold Control Input, then press On/Off Footswitch to toggle On/Off.
**STEREO OUT** - Plug in to Output 2. Nemesis will auto-detect input and output connections.
**MASTER VOLUME** - Press+hold Control Input, then turn Mix Knob to adjust.
**TAP TEMPO** - Tap footswitch at least twice to set the delay time.
**HOLD/FREEZE** - Press+hold Tap Footswitch for infinite repeats.
**CONTROL INPUT**- Press to enable external expression control.
**INTENSITY** - Function varies per engine:

| Effect Engine | MIN | MID | MAX |
|---|---|---|---|
| DIGITAL | High Cut | Clean | Low Cut |
| DIFFUSE | Clean | Light Diffusion | High Diffusion |
| ANALOG | Dark | Warm | Bright |
| TAPE | Warm | Saturated | Clean |
| NOISE TAPE | Dark | Warm | Bright |
| DEGRADE | Clean | Thin, Distorted | Aliased |
| SHIFTER | -Octave +m3rd | +M3rd +4th +5th | +Octave |
| HELIX | Warm | Clean | Bright |
| REVERSE | Single Tap | | Multi-Tap |
| SWEEPER | Low Q | Medium Q | High Q |
| RHYTHMIC | 1 2 3 4 | 5 6 7 | 8 |
| SLAPBACK | Warm | Clean | Bright |

### PRESETS

Press Select Button to load, press+hold to save. LED blinks slowly when save is complete.

### NEURO APP

Available for iOS and Android. Allows for advanced editing, saving, and sharing presets.

### USERS GUIDE

Get the full User's Guide, software tools, updates, and additional information at
**www.sourceaudio.net/products/nemesis**