

Cabinetware Product Installation

All Iver cabinetware pieces are installed using a rear-fix method, meaning that no screws are visible from the front of the fixing surface. This allows for a seamless look and feel. Iver cabinetware is also all supplied with the required bolts needed for installation.

All Iver cabinetware pieces are sold with the required bolts included.

Please find some basic installation instructions below.

1. Using your preferred method mark the product fixing points on the surface where you are installing the product – we recommend drilling from the front to avoid any splintering showing on your surface.
2. Drill a 4mm pilot hole at each fixing point.
3. Insert the supplied M4 threaded bolt from the rear of the fixing surface and affix the product.
4. Hand-tighten bolts with a screwdriver to avoid over-tightening or stripping the screws. Installation instructions for affixing the Osaka Large Half Moon Pull to a door can be found using the QR.

*Installation instructions for affixing the Osaka Large Half Moon Pull to a door can be found using the QR code below.

Please note: If pulls are installed on integrated appliance drawers, doors or larger cupboards, we recommend adding a washer for added durability (not supplied.)

@iver_life
iver-life.com

Installation Guides

Certified B Corporation
Learn more at bcorp.com