



NO-DIG EDGING KIT EASY TO INSTALL



INSTALLATION INSTRUCTIONS



- 1** Clear the installation area of loose soil and debris. Place edging on the cleared surface with anchoring tabs flat on the soil.



- 2** Pound spikes through tabs every 2-3 feet. Depending upon soil type and garden shape, some designs will require more frequent anchoring.



- 3** Backfill to the top of the edging with mulch, rock, or other ground cover. Assure tabs are completely covered by bedding material.

HELPFUL TIPS & INFORMATION

Installation:

Certain conditions and landscape designs will require more spikes than others. Vigoro spiral anchoring spikes are sold separately in stores and online.

Use a rubber mallet to pound spikes into the ground. Pound spikes only to the top of the edging tab. Too much tension on tabs can result in wavy edging.

Connect edging by overlapping the end-most tabs. Insert a single spike through both tabs and pound so the spike is secure in the ground.

Preparation:

Soil must be level. Assure no debris is under the edging tabs. Do not install edging on top of mulch, pebbles, or grass.

Compact soil can reduce spike movement and frost heave.

To use with weed fabric, install edging over the fabric. Spikes will easily pierce fabric.

Allow the edging to relax in the sun prior to installation and pull tightly between anchoring points. Doing so will reduce undesirable waves.