



- A |** Mount the S.S. back box to the the junction box. Secure to wall at top and bottom if necessary, through provided mounting holes.
- B |** Make all electrical connections - SEE WIRING DIAGRAM BELOW.
- C |** Install internal driver box to S.S. back box with (2) acorn nuts provided.
- D |** Install shade starting from the bottom and moving up to the top. While apply gentle pressure, work the leading edge of the shade between the internal driver box and the S.S. back box. Once the shade has bottomed out, check to make sure the top and bottom of the shade are flush with S.S. back box.



0-10V Dimming

## WIRING DIAGRAM

For illustration purposes only. Consult control manufacturer's spec. sheets for specific wiring requirements and fixture capacity.

### NOTICE:

- Wire according to appropriate manufacturers wiring diagrams
- **WARNING:** Risk of shock from energized equipment.
- Always turn power OFF and lock out during fixture installation
- This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- SUITABLE FOR DAMP LOCATIONS
- CONTACT MANUFACTURER FOR LED REPLACEMENT

### WARNING:

- **LIGHTART IS NOT LIABLE FOR DAMAGE DUE TO MISWIRING 0-10 VOLT CONTROL WIRES, OR LOW VOLTAGE LED WIRES TO LINE VOLTAGE.**



### LED DRIVER

- Provided by LightArt
- Mounted in driver box w/ 6-32 k-lock nuts.