


Geberit

SIGMA 20 ROUND BUTTON FLUSH PLATE



Features

- For use with Geberit cisterns
- Dual flush
- Made from ABS
(SIG-20BSS made from stainless steel)



Available in

- | | | |
|---|---|--|
|  |  |  |
| Chrome with
Matte Chrome Trim
SIG20-C | Matte Chrome
with Chrome Trim
SIG20-S | Brushed Steel
with Chrome Trim
SIG20-BSS |
|  |  | |
| Matte White
with White Trim
SIG20-WH | Matte Black
with Black Trim
SIG20-BL | |

Cleaning & Care

- Regularly clean with mild soapy water using a microfibre cloth.
- In highly polluted or coastal locations, we recommend cleaning 2-3 times per week.
- Do not use harsh detergents, bleach, cream cleaners or citrus based cleaners. These substances are abrasive and will damage the surface.
- Do not use undue pressure and wipe in one direction only.

We aim to ensure that specifications are correct at the time of publication. All measurements are shown in millimetres. Always use measurements of actual product received for final specification as the technical drawing may contain differences. Due to printing limitations, physical colour may vary from the image shown. Fienza reserves the right to make modifications without prior notice.