


Equity®

QUARTZ ALARM CLOCK

OPERATING INSTRUCTIONS MODEL # 14076/14077



To Start the Clock: -remove the battery cover. Insert a new "AA" battery (not included) in the battery compartment according to the (+) and (-) polarity as indicated. Replace the battery cover.

To Set Time: Turn the Adjust time knob (✓) to the correct time.

To Set Alarm: Turn the Adjust alarm knob (🔔) to the desired alarm time.

To Turn Alarm ON: Slide switch up to On position



To Turn Alarm OFF: Slide switch down to Off position



Always purchase the correct size and grade of battery most suitable for the intended use. Clean the battery contacts and also those of the device prior to battery installation. Ensure the battery is installed correctly with regard to polarity (+and-). Remove battery from equipment with is not to be used for an extended period of time. Remove used battery promptly. Please help in preservation of the environment and return used battery to an authorized depot.

Two Year Warranty (U.S.A.)

Equity products are warranted for two years from the date of consumer purchase against defects in material and workmanship. During this period such defects will be repaired, or the product will be replaced at Equity's option. This warranty does not cover damage caused by misuse or negligence. ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OR FITNESS AND MERCHANTABILITY, ARE LIMITED IN DURATION TO A PERIOD ENDING TWO YEARS FROM DATE OF PURCHASE. Some states do not allow limitations on how long an implied warranty lasts so the above limitation may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from State to State.

If your product is not working properly, please send:

-the product
-a letter explaining the problem
-and \$5.00 for postage and handling to:
Equity by La Crosse
Warranty Department
2830 26th St. S.
La Crosse, WI 54601

Made in China

Printed in China

www.equitybylacrosse.com/support