

WARRANTY & SUPPORT

This Equity product is warranted for 2 years for defects in material and workmanship. In accordance with the Song-Beverly Act, in the state of California, the warranty on this item becomes effective on the date of delivery. During this period such defects will be repaired, or the product will be replaced at Equity's option, without charge. This warranty does not cover damage caused by misuse or negligence.

ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OR FITNESS AND MERCHANTABILITY, ARE LIMITED IN DURATION TO A PERIOD ENDING TWO YEARS FROM DATE OF PURCHASE.

Some states do not allow limitations on how long an implied warranty lasts so the above limitation may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

If your product is not working properly, please send:

Your product

A letter explaining the problem and \$5.00 for postage and handling to:

Equity by La Crosse

Warranty Department

2830 26th St S.

La Crosse, WI 54601

For more information and support visit:

www.lacrossetechnology.com/support



WARNING: This product can expose you to chemicals including acrylonitrile, 1, 3-butadiene, and styrene, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to:

www.P65Warnings.gov

Made in China - Printed in China

Page | 4

Equity

QUARTZ FOLDING TRAVEL ALARM CLOCK



Model: 20080

DC: 070524

Page | 1

POWERUP

1. Remove Battery Cover.
2. Insert one new “AA” alkaline Battery into the battery compartment according to polarity (+ /-).

TIME

Set Time:

Turn the Time Set Knob clockwise to the correct time.

ALARM

Set Alarm:

Turn the Alarm Set Knob counter-clockwise to your desired wakeup time.

Turn Alarm ON:

Slide the Alarm Switch to the left to activate the alarm.

Turn Alarm OFF:

Slide the Alarm Switch to the right to deactivate the alarm.

FEATURES

- Luminous Hands and Hour dots
- Loud Beep Alarm
- Quartz Movement
- Protective folding case

SPECIFICATIONS

Movement: Quartz – Step Motion

Power Requirements: 1 “AA” Alkaline Battery (Not Included)

Battery Life: 12+ Months (1 Battery)

Dimensions: 3.0in L x 2.50 in W x 3.50 in H
(7.62cm L x 6.35cm W x 8.89cm H)

CARE AND MAINTENANCE

When batteries of different brand or type are used together, or new and old batteries are used together, some batteries may be over-discharged due to a difference of voltage or capacity. This can result in venting, leakage, and rupture and may cause personal injury.

- Always purchase the correct size and grade of battery most suitable for intended use.
- Always replace the whole set of batteries at one time, taking care not to mix old and new ones, or batteries of different types.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the battery is installed correctly with regard to polarity (+ and -).
- Remove the battery from product during periods of non-use. Battery leakage can cause corrosion and damage to this product.
- Remove a used battery promptly.
- For recycling and disposal of the battery, and to protect the environment, please check the internet or your local phone directory for local recycling centers and/or follow local government regulations.