

WARRANTY & SUPPORT

This Equity product is warranted for 2 years for defects in material and workmanship. Per the Song-Beverly Act, in the state of California, the warranty on this item becomes effective on the date of delivery.

During this period such defects will be repaired, or the product will be replaced at Equity's option, without charge. This warranty does not cover damage caused by misuse or negligence.

ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OR FITNESS AND MERCHANTABILITY, ARE LIMITED IN DURATION TO A PERIOD ENDING TWO YEARS FROM DATE OF PURCHASE.

Some states do not allow limitations on how long an implied warranty lasts so the above limitation may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from State to State.

If your product is not working properly, please send:

Your product

A letter explaining the problem and \$5.00 for postage and handling to:

Equity by La Crosse

Warranty Department

2830 26th St S.

La Crosse, WI 54601

For Full Warranty Details, Visit: <https://www.lacrossetechnology.com/pages/warranty-eb1-1>

Patents: www.lacrossetechnology.com/pages/patent

STAY CONNECTED

Ask questions, watch set up videos, and provide feedback on our social media outlets.

Follow La Crosse Technology on Youtube, Facebook, Instagram, and X (Twitter).



⚠ WARNING: This product can expose you to chemicals including acrylonitrile, 1, 3-butadiene, and styrene, which are known to the State of California to cause cancer and birth defects or other reproductive harm.

For more information go to: www.P65Warnings.ca.gov

Made in China - Printed in China

Equity

WAYLON INDOOR/OUTDOOR WALL CLOCK




Model: 29005

DC:101624

Power Up

1. Pull the Clock Movement Cover up to gain access to the battery compartment.
2. Insert 1 fresh AA battery into your clock according to the polarity markings.
3. Rotate the Time Set Wheel to set your time.
4. Replace the cover and enjoy!



MOUNTING

- Use the Integrated Hanging Hole on the back to mount the clock indoors or outdoors.
- For accurate readings and longevity outdoors, choose a protected location not subject to direct weather elements (sunlight, rain, snow, etc.); under an eave on a shaded north-facing wall is often a good solution.

THERMOMETER / HYGROMETER

The clock has built-in analog sensors that measure surrounding temperature and humidity. These sensors are precalibrated and self-adjusting and do not require a battery.

SPECIFICATIONS

- **Time Digit Height:** 0.6 in (1.52cm)
- **Movement:** Quartz - Step Motion
- **Numerals:** Arabic (1, 2, 3, 4, 5, 7, 8, 9, 10, 11)
- **Lens Type:** Glass
- **Construction:** Plastic, Glass, Metal
- **Temperature Range:** 40°F to 120°F
- **Humidity:** Humid, Normal, Dry
- **Placement:** Indoor
- **Mounting Type:** Wall Mount
- **Power Requirements:** 1 "AA" Alkaline Battery (Not Included)
- **Battery Life:** 7+ Months
- **Dimensions:** 10.0 in (25.4cm) Diameter 2.0 in (5.08cm) Depth

CARE & MAINTENANCE

When batteries of different brand or type are used together, or new and old batteries are used together, some batteries may be over-discharged due to a difference of voltage or capacity. This can result in venting, leakage, and rupture and may cause personal injury.

- Always purchase the correct size and grade of battery most suitable for intended use.
- Always replace the whole set of batteries at one time, taking care not to mix old and new ones, or batteries of different types.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries are installed correctly with regard to polarity (+ and -).
- Remove batteries from product during periods of non-use. Battery leakage can cause corrosion and damage to this product.
- Remove used batteries promptly.
- For recycling and disposal of batteries, and to protect the environment, please check the internet or your local phone directory for local recycling centers and/or follow local government regulations.