

LA CROSSE
CLOCK CO.

11.8-Inch Tide Wall Clock



Model: 425-3831


Tide Information

- High and low tides alternate about every six hours.
- For accurate tide forecasting, it is important to set your Tide Position when your local high tide occurs the same day as a full moon.
- Use a local tide table or select your location from: <https://tidesandcurrents.noaa.gov/>

Setup

1. Rotate the wheel to move the hand to the High Tide position.
2. Insert 1-AA battery into the battery compartment on the day of a full moon at exactly the time of the high tide in your location.
3. Hang on the wall and enjoy!

Note: The clock should be correct to within 30 minutes.



SPECIFICATIONS

- **Digit Height:** 0.50 in (1.17 cm)
- **Quartz Movement:** Tide
- **Lens Type:** Glass
- **Numerals:** Arabic
- **Construction:** Beechwood, Plastic, Glass, Metal
- **Placement:** Indoors
- **Mounting Type:** Wall Hanging
- **Power Requirements:** 1 “AA” Alkaline Battery (Not Included)
- **Battery Life:** 12+ Months
- **Clock Face Dimension:** 11.46 in (29.1 cm)
- **Dimensions:** 11.81 in (30.0 cm) Diameter 1.81 in (4.6 cm) Deep

CARE & MAINTENANCE

When batteries of different brand or type are used together, or new and old batteries are used together, some batteries may be over-discharged due to a difference of voltage or capacity. This can result in venting, leakage, and rupture and may cause personal injury.

- Always purchase the correct size and grade of battery most suitable for the intended use.
- Do Not Mix Old and New Batteries.
- Do Not Mix Alkaline, Standard, or Rechargeable Batteries.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the battery is installed correctly with regard to polarity (+ and -).
- Remove the battery from product during periods of non-use. Battery leakage can cause corrosion and damage to this product.
- Remove a used battery promptly.
- For recycling and disposal of the battery, and to protect the environment, please check the internet or your local phone directory for local recycling centers and/or follow local government regulations.

Warranty & Support

This product is warranted to be free from defects in material and workmanship under normal use and service for a period of two years. Per the Song-Beverly Act, in the state of California, the warranty on this item becomes effective on the date of delivery. The warranty will not apply to defects resulting from abuse, accidents, or misuse. If a defect that is covered by this warranty arises during the warranty period, promptly return the clock (postage prepaid) with proof of purchase showing the date the clock was purchased to the following address and such defects will be repaired, or the products will be replaced at La Crosse Clock Company option without charge.

La Crosse Clock
Warranty Department
2830 South 26th Street.
La Crosse, WI 54601

Contact Us for Online Support:

bit.ly/contact_techsupport

Patents:

www.lacrossetechnology.com/pages/patents

Scan for Support



Let's Be Social!

Ask questions, watch set up videos, and provide feedback on our social media outlets. Follow La Crosse Technology on YouTube, Facebook, and Instagram.



⚠ WARNING: This product can expose you to chemicals including acrylonitrile, 1, 3-butadiene, and styrene, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to: www.P65Warnings.ca.gov