

LA CROSSE
CLOCK CO.


Twin Bell Alarm Clock



Models: 617-3314BG | 617-3314MY | 617-3314RR
617-3314SG | 617-3314TP | 617-3314W

POWER UP

1. Insert 1 fresh AA battery into your clock according to the polarity markings.
2. Turn the Time Set Knob to set your time.



TIME ALARM

1. Turn the Alarm Set Knob to set your alarm time.
2. Slide the Alarm ON | OFF Switch to activate (ON) or deactivate (OFF) your alarm.

POSITION

Place the clock on a bedside table, desk, or other flat surface.

SPECIFICATIONS

- **Quartz Movement:** Silent Sweep
- **Lens Type:** Glass Lens
- **Construction:** Metal, Glass
- **Placement:** Indoor
- **Mounting Type:** Table Mount
- **Numerals:** Arabic
- **Alarm:** Up to 96 dBs
- **Power Requirements:** 1 “AA” Alkaline Battery (Not Included)
- **Battery Life:** 12+ Months
- **Dimensions:** 3.95 in L x 2.05 in W x 5.95 in H (10.03cm L x 5.20cm W x 15.11cm H)



 **WARNING:** This product can expose you to chemicals including acrylonitrile, 1, 3-butadiene, and styrene, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to: www.P65Warnings.ca.gov

LET'S BE SOCIAL!

Ask questions, watch set up videos, and provide feedback on our social media outlets. Follow La Crosse Technology on YouTube, Facebook, and Instagram.



CARE & MAINTENANCE

When batteries of different brand or type are used together, or new and old batteries are used together, some batteries may be over-discharged due to a difference of voltage or capacity. This can result in venting, leakage, and rupture and may cause personal injury.

- Do not mix Alkaline, Lithium, standard, or rechargeable batteries.
- Always purchase the correct size and grade of battery most suitable for intended use.
- Always replace the whole set of batteries at one time, taking care not to mix old and new ones, or batteries of different types.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries are installed correctly with regard to polarity (+ and -).
- Remove batteries from product during periods of non-use. Battery leakage can cause corrosion and damage to this item.
- Remove used batteries promptly.
- For recycling and disposal of batteries, and to protect the environment, please check the internet or your local phone directory for local recycling centers and/or follow local government regulations.

WARRANTY & SUPPORT

This product is warranted to be free from defects in material and workmanship under normal use and service for a period of two years. Per the Song-Beverly Act, in the state of California, the warranty on this item becomes effective on the date of delivery. The warranty will not apply to defects resulting from abuse, accidents, or misuse. If a defect that is covered by this warranty arises during the warranty period, promptly return the clock (postage prepaid) with proof of purchase showing the date the clock was purchased to the following address and such defects will be repaired, or the products will be replaced at La Crosse Clock Company option without charge.

La Crosse Clock Company
Warranty Department
2830 South 26th Street.
La Crosse, WI 54601

Contact Us for Online Support:

bit.ly/contact_techsupport

Patents:

www.lacrossetechnology.com/pages/patents

Scan to Contact
Support

