

LA CROSSE  
CLOCK CO.

## DAILY FLIP TABLETOP CLOCK WITH CALENDAR




**Models:** 636-379B, 636-379BL, 636-379G,  
636-379P, 636-379W

## Power Up

1. Insert 1 fresh AA alkaline battery (not included), according to polarity, into the Movement. Be sure the Battery Ribbon is under the battery for easy removal.
2. Set the Day and Date using the corresponding buttons on top of the clock.
3. Mount on a place on tabletop and enjoy!

**Note:** You will need to manually adjust the Day and Date each day.



## Set Alarm

1. Rotate the Alarm Set Knob to set the alarm time.
2. Press down on the Alarm ON/OFF button on the top center of the clock to activate the alarm.

**Deactivate and activate the Alarm:** Press and release the button on the top center of the clock to deactivate a sounding alarm. Press again to activate for the next day.

## Specifications

**Time Digit Height:** 0.25 in (0.64cm)

**Quartz Movement:** Step Motion

**Lens Type:** Plastic

**Numerals:** Arabic

**Alarm Sound:** Up to 70 dB

**Construction:** Plastic, Metal

**Placement:** Indoor

**Mounting Type:** Tabletop

**Power Requirements:** 1 "AA" Alkaline Battery (Not Included)

**Battery Life:** 12+ Months

**Clock Face Dimension:** 2.44 in (6.2 cm) Diameter

**Dimensions:** 6.73 in L x 2.17 in W x 3.54 in H  
(17.1 cm L x 5.5 cm W x 9.0 cm H)

## Care and Maintenance

When batteries of different brand or type are used together, or new and old batteries are used together, some batteries may be over-discharged due to a difference of voltage or capacity. This can result in venting, leakage, and rupture and may cause personal injury.

- Always purchase the correct size and grade of battery most suitable for the intended use.
- Do Not Mix Old and New Batteries.
- Do Not Mix Alkaline, Standard, or Rechargeable Batteries.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the battery is installed correctly with regard to polarity (+ and -).
- Remove the battery from product during periods of non-use. Battery leakage can cause corrosion and damage to this product.
- Remove a used battery promptly.
- For recycling and disposal of the battery, and to protect the environment, please check the internet or your local phone directory for local recycling centers and/or follow local government regulations.

# Warranty and Support

This product is warranted to be free from defects in material and workmanship under normal use and service for a period of two years. Per the Song-Beverly Act, in the state of California, the warranty on this item becomes effective on the date of delivery. The warranty will not apply to defects resulting from abuse, accidents, or misuse. If a defect that is covered by this warranty arises during the warranty period, promptly return the clock (postage prepaid) with proof of purchase showing the date the clock was purchased to the following address and such defects will be repaired, or the products will be replaced at La Crosse Clock Company option without charge.

La Crosse Clock Company  
Warranty Department  
2830 South 26<sup>th</sup> Street.  
La Crosse, WI 54601

Contact Us for Online Support:

[bit.ly/contact\\_techsupport](https://bit.ly/contact_techsupport)

Patents:

[www.lacrossetechnology.com/pages/patents](https://www.lacrossetechnology.com/pages/patents)

Scan for Support



## Let's be Social!!

Ask questions, watch set up videos, and provide feedback on our social media outlets. Follow La Crosse Technology on YouTube, Facebook, and Instagram.



**⚠ WARNING:** This product can expose you to chemicals including acrylonitrile, 1, 3-butadiene, and styrene, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to: [www.P65Warnings.ca.gov](https://www.P65Warnings.ca.gov)