

LA CROSSE
CLOCK CO.

Cuckoo Clock





Model: W70063

POWER UP

1. Remove Battery Cover by lifting bottom tab.
2. Insert 1 AA battery (not included), into the clock movement slot and 2 AA batteries into the outer slots for Cuckoo Features. Install batteries according to polarity.
3. Rotate the Time Set Wheel to set the time.
4. Place on a tabletop or hang on a wall and enjoy!

Learn more from our video: bit.ly/wallclock_setup



SMART LIGHT SENSOR

ON- Cuckoo sounds every hour.

AUTO- Cuckoo sounds when light is detected.

OFF- Cuckoo is silent.

1. Battery Compartments
2. Time Set Wheel
3. Cuckoo Sound (3-Cuckoos at 3:00, etc.):
 - ON-** Cuckoo sounds every hour.
 - AUTO-** Cuckoo will sound if light is detected.
 - OFF-** Cuckoo is silent.
4. Demo Button-Press and release-the Cuckoo will sound the current hour.
5. Volume Selection: Select 3 levels of volume.
6. Light Sensor: Intelligent Light Control

TIPS

Cuckoo Sound slows or the Clock loses Time:

Replace batteries. Follow Power Up steps on page 2.

Cuckoo does not sound:

When on AUTO the cuckoo will not sound in low light.

When OFF, the cuckoo will not sound.

Manual Cuckoo Sound Sync.

Remove all batteries. Turn the hands to 12:00. Reinsert batteries.

Set to current time.

SPECIFICATIONS

Quartz Movement: Step Motion

Lens Type: No Lens

Numerals: Arabic

Construction: Plastic, Metal

Placement: Indoor

Mounting Type: Tabletop or Wall Hanging

Volume: High-Up to 75 decibels

Medium-Up to 65 decibels

Low-Up to 55 decibels

Power Requirements: 3 "AA" Alkaline Batteries (Not Included)

Battery Life: 12+ Months

Dimensions: 5.99-in L x 3.52-in W x 8.00-in H

(15.21 cm L x 8.94 cm W x 20.32 cm H)



WARNING: This product can expose you to chemicals including acrylonitrile, 1, 3-butadiene, and styrene, which are known to the State of California to cause cancer and birth defects or other reproductive harm.

For more information go to: www.P65Warnings.ca.gov

WARRANTY & SUPPORT

This product is warranted to be free from defects in material and workmanship under normal use and service for a period of two years. Per the Song-Beverly Act, in the state of California, the warranty on this item becomes effective on the date of delivery. The warranty will not apply to defects resulting from abuse, accidents, or misuse. If a defect that is covered by this warranty arises during the warranty period, promptly return the clock (postage prepaid) with proof of purchase showing the date the clock was purchased to the following address and such defects will be repaired, or the products will be replaced at La Crosse Clock Company option without charge.

La Crosse Clock Company
Warranty Department
2830 South 26th Street.
La Crosse, WI 54601



SCAN QR CODE

Online support: bit.ly/w70063_support

Patents: www.lacrossetechnology.com/pages/patents

LET'S BE SOCIAL!

Ask questions, watch setup videos, and provide feedback on our social media outlets. Follow La Crosse Technology on YouTube, Facebook, and Instagram.



All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher.

This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences. All trademarks and patents are recognized.

CARE & MAINTENANCE

Battery Replacement Instructions

When batteries of different brand or type are used together, or new and old batteries are used together, some batteries may be over-discharged due to a difference of voltage or capacity. This can result in venting, leakage, and rupture and may cause personal injury.

- Do Not Mix Old and New Batteries.
- Do Not Mix Alkaline, Standard, or Rechargeable Batteries.
- Always purchase the correct size and grade of battery suitable for the intended use.
- Clean the battery contacts and those of the device prior to battery installation.
- Ensure the batteries are installed correctly with regard to polarity (+ and -).
- Remove batteries from product during periods of non-use. Battery leakage can cause corrosion and damage to this product.
- Remove used batteries promptly.
- For recycling and disposal of batteries, and to protect the environment please check the internet or your local phone directory for local recycling centers and / or follow local government regulations.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



LA CROSSE
CLOCK CO.

