


25-Inch Beadboard Clock-Thermometer-Hygrometer



Setup

1. Remove the movement cover by twisting in the direction indicated.
2. Insert 1 new “AA” Alkaline battery (not included) according to the polarity marked in the battery compartment.
3. Turn the time set knob to the desired time.
4. Replace movement cover.

Note: The quartz movement will keep the clock running accurately. If the clock does not operate, or steadily loses time, replace the battery.

Thermometer/Hygrometer

During shipment, the temperature mechanism on your thermometer or hygrometer may become slightly misaligned, resulting in inaccurate temperature readings.

To correct this problem, you will need to re-calibrate. Steps to do this are as follows:

1. Take the thermometer to an area in your home near a wall thermostat or other temperature-measuring device that has an accurate temperature reading.

2. Rotate the black temperature mechanism located on the back of your temperature left or right so that the thermometer hand is positioned over the degree mark that matches your measuring device.
3. Hygrometer will adjust in the same manner as the thermometer.

Limited Warranty

This product is warranted to be free from defects in material and workmanship under normal use and service for a period of 1 year from the date of sale to the customer. Warranty will not apply to defects resulting from abuse, accidents, or misuse. If a defect that is covered by this warranty arises during the warranty period, promptly return the clock (postage prepaid) with proof of purchase showing the date the clock was purchased to the following address and such defects will be repaired, or the products will be replaced at La Crosse Clock Company option without charge.

La Crosse Clock Company
Warranty Department
2830 South 26th Street
La Crosse, WI 54601

www.lacrosseclock.com/support



Specifications

Power Requirements: 1 AA LR6 Alkaline Battery
Battery Life: over 12 months
Dimensions: 25.10"H x 8.00"W x 0.57"D
(63.75 cm H x 20.32 cm W x 1.46cm D)

Care and Maintenance

- Always purchase the correct size and grade of battery most suitable for intended use.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the battery is installed with correct polarity (+ and -).
- Remove battery from equipment which is not to be used for an extended period of time.
- Remove expired battery promptly.
- The specs of this wall clock may change without prior notice.
- Improper use or unauthorized opening of housing voids warranty.

Made in China – Printed in China

www.lacrosseclock.com/support