


## MODEL RI-500 PARTS DIAGRAM



## MODEL RI-500 PARTS LIST

| NO. | DESCRIPTION           | CODE     | QTY. |
|-----|-----------------------|----------|------|
| 1   | Handle Ass'y (1)      | Z325A-01 | 1    |
| 2   | Shoulder Screw        | Z325A-02 | 1    |
| 3   | Handle Ass'y (2)      | Z325A-03 | 1    |
| 4   | Handle Spring         | Z325A-04 | 1    |
| 5   | Pivot Pin             | Z325A-05 | 1    |
| 6   | Pawl                  | Z325A-06 | 1    |
| 7   | 4 X 13 Dowel Pin      | Z325A-07 | 2    |
| 8   | M5 X 10 Cap Hex Screw | Z325A-08 | 2    |
| 9   | M4 X 6 Screw          | Z325A-09 | 1    |
| 10  | M6 U Nut              | Z325A-10 | 1    |
| 11  | Stationary Blade      | Z325A-11 | 1    |
| 12  | Moving Blade          | Z325A-12 | 1    |
| 13  | Pivot Screw           | Z325A-13 | 1    |
| 14  | Spring (A)            | Z325A-14 | 1    |
| 15  | Spring (B)            | Z325A-15 | 1    |
| 16  | Ratchet Pawl          | Z325A-16 | 1    |
|     |                       |          |      |