


MODEL S-32CC PARTS DIAGRAM



MODEL S-32CC PARTS LIST

NO.	DESCRIPTION	CODE	QTY.	NO.	DESCRIPTION	CODE	QTY.
1	CE-12.7 Snap Ring	26-04	4	49	M4 X 5 Screw (C.P.)	55A-24	1
2	Pin (31)	26-03	2	50	Body Handle	26-39	1
3	Latch	32C-01	1	51	Body Handle Grip	26-40	1
4	M8 X 35 Screw	32C-02	1				
5	M8 Lock Washer	40-25	1				
6	4 X 36 Drive Pin	26-02	1				
7	Spring Holder	26-06	1				
8	Spring (81)	26-07	1				
9	Head	32CE-02	1				
10	Anvil Blade	32C-04	1				
11	M5 X 10 Screw (D.P.)	55A-11	1				
12	Cylinder Head	32CE-01	1				
13	Cutter Blade	32C-06	1				
14	Spring (192)	32C-07	1				
15	Ram	32C-08	1				
16	Blade Screw	32-09	1				
17	P-45 Back-Up Ring (B.C.)	32-10	1				
18	P-45 O-Ring	32-11	1				
19	Exhaust Valve Screw	26-19	1				
20	Copper Gasket (4)	26-20	1				
21	Spring (68)	26-21	1				
22	1/4" Ball	26-22	1				
23	Spring (4)	16-48	1				
24	3/16" Ball	16-49	2				
25	M6 X 15 Screw (F.P.)	32-23	1				
26	2.5 X 20 Drive Pin	32-13	1				
27	Release Knob Label	32-14	1				
28	Release Knob	32-15	1				
29	Release Valve Stem	32-16	1				
30	P-3 O-Ring	16-36	1				
31	7/32" Ball	16-26	1				
32	Spring (76)	16-39	1				
33	9/32" Ball	16-40	1				
34	M10 X 10 Screw (F.P.)	16-41	1				
35	PS-9 Pent Seal	32-18	1				
36	P-9 Back-Up Ring (B.C.)	32A-01	1				
37	VC-9 Oil Seal	32A-02	1				
38	Pump Piston	32-21	1				
39	CE-7 Snap Ring	40-49	4				
40	Pin (5)	26-29	2				
41	Pump Handle	26-30	1				
42	Pump Handle Grip	26-31	1				
43	Body	32A-04	1				
44	Suction Tube	26-34	1				
45	Filter Base Ass'y	26-35	1				
46	P-38 O-Ring	26-37	1				
47	Oil Reservoir (10)	32A-03	1				
48	Reservoir Cap	410-55	1				