




# Huskie TOOLS

## SP-24 BREAKDOWN



## **SP-24 PARTS LIST**

<b>NO.</b>	<b>DESCRIPTION</b>	<b>CODE</b>	<b>QTY.</b>
1	M8 Hex. Nut	40-24	8
2	M8 Lock Washer	40-25	8
3	Main Head	24-02	1
4	Spacer	24-03	1
5	Head Shear	24-04	1
6	Stud Bolt (21)	24-05	4
7	Slide Pin	20-71	1
8	Spring (144)	85-37	1
9	2 X 10 Drive Pin (AW)	5-09	1
10	Pin (142)	24-06	2
11	CE-10 Snap Ring	40-16	4
12	Latch	24-07	1
13	Blade	24-08	1
14	M5 X 5 Screw (C.P.)	RD-16	1
15	Cylinder Head	P24-01	1
16	Spring (379)	P24-02	1
17	Ram	P24-03	1
18	Blade Screw	16-19	1
19	P-34 Back-Up Ring (B.C.)	85-22	1
20	P-34 O-Ring	85-23	1
21	Cylinder	P24-04	1
22	Female Coupler IZUMI	100-24	1
23	Adapter 3/8" PT-M. 3/8" NPT-F.	P85-80	1
24	Female Coupler P.H. Type	P85-81	1