




Huskie
TOOLS

MODEL SP-32

Parts Diagram



parts@huskietools.com

www.huskietools.com



Huskie
TOOLS

MODEL SP-32

Parts List

NO.	DESCRIPTION	CODE	QTY.
1	M10 HEX. NUT	40-31	8
2	M10 LOCK WASHER	40-32	8
3	MAIN HEAD	32-01	1
4	4 X 36 DRIVE PIN (AW)	26-02	1
5	PIN (31)	26-03	2
6	CE-12.7 SNAP RING	26-04	4
7	LATCH	26-05	1
8	SPRING HOLDER	26-06	1
9	SPRING (81)	26-07	1
10	HEAD SHEAR	32-02	1
11	STUD BOLT (2)	26-09	4
12	SPACER	32-03	1
13	M5 X 10 SCREW	P32-01	1
14	CYLINDER HEAD	P32-02	1
15	BLADE	32-06	1
16	SPRING (182)	32-07	1
17	RAM	P32-03	1
18	BLADE SCREW	32-09	1
19	P-58 BACK-UP RING (B.C.)	P32-04	1
20	P-58 O-RING	P32-05	1
21	CYLINDER	P32E-06	1
23	M6 X 35 SCREW	P32-E04	2
24	CYLINDER BAND	P32E-01	1
25	M6 HEX. NUT	16-01	1
26	CARRY HANDLE	P32-09	1
27	GRIP BAND	P32-E03	1
28	METRIC STD. ADAPTER	RD-13	1
29	MALE COUPLER	MC-8/DC-8	1