


Customer Service : (800) 525-2655, customercare@kalco.com

WARNING - TO REDUCE THE RISK OF FIRE OR INJURY:

1. If you are unfamiliar with electrical wiring, call a qualified electrician to install this unit. More than one person may be necessary to install fixture, make sure you have enough qualified help.
2. Turn off the power to the fixture's circuit at the service panel. Use a voltage detector to verify that the power is off.
3. DO NOT install bulb which exceeds the maximum wattage specified on the socket label.


Fixture Assembly

- 1** Step 1. Determine the position of anchor sleeve and install the anchor sleeve on wall. Hold up the fixture and attach the crossbar to junction box with two supplied screws.




- 2** Step 2. Connect the supply wires to fixture wires with wire connectors.

The steel cable is to prevent the heavy fixture assembly falling down during maintenance.




- 3** Step 3. Attach the fixture assembly to crossbar with two supplied knurled knobs.

Use 2 stainless steel self-tapping screw (not supplied) to secure the fixture assembly against the wall through the threaded collar, then screw the knob onto the collar.




- 4** Step 4. Install the bulbs into socket.

DO NOT use bulb exceeding the maximum wattage specified on the socket label.



- 5** Step 5. Place the face cover over the fixture assembly and secure the screws on top and at bottom.



Remove the top cover for bulb replacement.

