



# USER MANUAL

---


## Poultry Waterer

1-Gallon Capacity

## High-Rise Waterer

2-Gallon Capacity

with RentACoop® Horizontal Nipple and  
Auto-fill Cup Drinking Attachments



---

5D-H5XP-5JRX  
D5-8HF8-E0BE  
1G-1019-CHWT |  
ST-1GAL-5FDP  
25.02

## TABLE OF CONTENTS


---

PACKAGE CONTENTS	3
HORIZONTAL NIPPLE	
BENEFITS	4
SETUP	4
TRAINING TIPS	5
INSTRUCTIONS	5
AUTO-FILL CUP	
BENEFITS	6
SETUP	6
INSTRUCTIONS	7
MAINTENANCE	8
CONTACT INFORMATION	BACK COVER


## PACKAGE CONTENTS

---

- 1x Waterer with  
1x Anti-Roost Cone



- 2x Auto-Fill Cup



- 2x Horizontal Nipple with  
Dribble Dish [attached]



- 1x Mounting Kit



---

When introducing a new type of waterer to your animals, completely remove the previous water source and replace it with the new waterer in the same location.

The position of the drinker depends on the height of your animal. **We do not provide an exact measurement as all animal sizes vary. Please use your best judgement when installing.**

## HORIZONTAL NIPPLE

---

### BENEFITS

Perfect for use in freezing temperatures when paired with a heating source/waterer deicer\*

Low-maintenance — no dirty water bowls to clean


Training your chickens to use the nipples is easy

*\*Heating source not included and is sold separately. For safety, please follow the directions that come with your heating source/waterer deicer*

*TIP FOR WINTER-USE: We recommend removing the Dribble Dish from horizontal nipple so that water doesn't pool and freeze in it. The dribble dish snaps on and off.*

### SETUP

---



The position of the red horizontal nipple should be eye-level with your animal[s].




## TRAINING TIPS

---

Mimic pecking by tapping on the nipple multiple times in front of your chickens so that they can see where to get the water.


Leave a drop of water on the **lip** of the horizontal nipple for your chickens to notice!



## INSTRUCTIONS

---

1. Screw the horizontal nipples into the pre-drilled holes and turn (clockwise) until tight.



## AUTO-FILL CUP

---

### BENEFITS

Perfect for use in warm weather and non-freezing temperatures

Chickens can dip their wattles in the cups to cool off on hot days


Suitable for cross-beaks

Water is visible to chickens

Requires absolutely no training

### SETUP


---




## INSTRUCTIONS

---

1. Screw the cups by their elbow into the pre-drilled holes of the waterer until tight (turn clockwise).
2. Twist the wingnut onto the exposed threads of the elbow from inside the bucket until tight (turn clockwise).



3. Place the waterer on a block or prop to allow the auto-fill cups to fully extend for proper functioning.



## MAINTENANCE :


---

**NOTE:** To prolong the life of your drinker, we recommend washing the entire drinker at least once a week.

**The bottle and lid are dishwasher-safe, top rack only. Disassemble drinker before cleaning.**

### CLEANING THE CUP-INSERT


*Remove the insert, empty any debris and return the insert back to the cup.*




**THIS PAGE IS INTENTIONALLY LEFT BLANK.**

## HOW TO CLEAN THE AUTO-FILL CUP

1. Clean and wipe any dirt or debris from the cup.
2. Pry one side of the tabs on the base to release the small plastic nodule out of its tab. Be careful not to break the nodules off.



3. There is a load-spring so make sure to take the base off slowly. Once you release the first nodule, the second tab will come off easy.
4. Check that all **water spouts** are clean of debris. You can use a toothpick if clogged.





RentACoop®

**QUESTIONS?**

CONTACT OUR  
**EGG - SPERTS**

**info@rentacoop.com**

**1 800-642-3571**

M-F 9-5 EST



@rentacoop  
#rentacoop