

USER MANUAL

Drinker

for Poultry | 32oz-Capacity
64oz-Capacity







TABLE OF CONTENTS

PACKAGE CONTENTS [32OZ]	4
PACKAGE CONTENTS [64OZ]	5
HOW TO INSTALL SLIDING LID	6
HOW TO USE SLIDING LID	7
DRINKER ATTACHMENT GUIDE	8-9
HOW TO ASSEMBLE DRINKER	10
TRAINING	11
MAINTENANCE	
HOW TO CLEAN DRINKER	11
USING THE EASY-CLEAN PLUG	11
CONTACT INFORMATION	BACK COVER

IMPORTANT:



The red horizontal nipple is intended for chicks seven days and older.



The versatile nipple can be used with chickens at any age.

PACKAGE CONTENTS [32OZ]



1x Drinker [32oz]



1x Sliding Lid



1x Easy-Plug (stored underneath lid)




1x Versatile Nipple



1x Horizontal Nipple




1x Coop Clip [32oz]



1x Coop Clip User Manual

PACKAGE CONTENTS [64OZ]



1x Drinker [64oz]



1x Sliding Lid



1x Easy-Plug (stored underneath lid)



1x Versatile Nipple



1x Horizontal Nipple




1x Coop Clip [64oz]




1x Coop Clip User Manual


HOW TO INSTALL SLIDING LID

1. Place the notches that are located on the inside of the lid into the tracks on sides of the drinker.



HOW TO USE SLIDING LID





BENEFITS OF HORIZONTAL NIPPLE


Perfect for use in freezing temperatures when paired with a heating source/waterer deicer*

Low-maintenance — no dirty water bowls to clean

Training your chickens to use the nipples is easy

**Heating source not included and is sold separately. For safety, please follow the directions that come with your heating source/waterer deicer*

TIP FOR WINTER-USE: We recommend removing the Dribble Dish from horizontal nipple so that water doesn't pool and freeze in it. The dribble dish snaps on and off.



Mimic pecking by tapping on the nipple multiple times in front of your chickens so that they can see where to get the water.

For the horizontal nipple, leave a drop of water on the protruding ledge for your chickens to notice!

HOW TO ASSEMBLE DRINKER

When introducing a new type of waterer to your animals, completely remove the previous water source and replace it with the new waterer in the same location.

DO NOT FILL DRINKER WITH WATER UNTIL DRINKER IS FIXED IN DESIRED LOCATION

1. Attach lid (See page 6 for help).

2. Screw in desired drinking attachment and turn clock-wise until tight.



3. Mount. See Coop Clip User Manual (included as a separate manual in this set).

MAINTENANCE

HOW TO CLEAN DRINKER

NOTE: To prolong the life of your drinker, we recommend washing the entire drinker at least once a week.


The drinker container and lid are dishwasher-safe, top rack only. Disassemble drinker before cleaning.

HOW TO USE EASY-CLEAN PLUG



The small silicone plug is located underneath the drinker lid can be removed.

It is used to stop the flow of water so that you can easily unscrew, move, and clean your cup without creating a mess.





RentACoop®

QUESTIONS?

CONTACT OUR
EGG - SPERTS

info@rentacoop.com

1 800-642-3571

M-F 9-5 EST



@rentacoop
#rentacoop