

Test Report GUARDIAN ANSI/ASSE Z359.18-2017

Pure Safety Group, Inc. 607 East Sam Houston Pkwy S Suite 800, Pasadena, TX 77053

Test Report Number: 2025052710715

Job Number: Test 882 Product SKU#: 10715

Product Type: Anchorage Connector

Product Description: 4 ft Concrete Strap with sheath - web loop/d-ring ends

Testing Standard: ANSI/ASSE Z359.18-17 Safety Requirements for Anchorage Connectors for Active Fall Protection Systems

Date(s) of Manufacture: 4/01/2025 Date(s) of Testing: 5/07/2025

REQUIREMENT VERIFICATION

| Requirement Description | <u>Clause/Section</u> | Result |
|---------------------------|------------------------------|------------------|
| Design Requirements | 3.1 Design Requirements | Meets or Exceeds |
| Performance Requirements | 3.2 Performance Requirements | Meets or Exceeds |
| Markings and Instructions | 5. Markings and Instructions | Meets or Exceeds |

QUALIFICATION TESTING

| Test Description | <u>Test Date</u> | Clause/Section | Result |
|-----------------------|------------------|--|--------|
| Static Strength (A) | 5/07/2025 | 4.2.1.1 Static Strength Testing of Type A Anchorage Connectors | Pass |
| Dynamic Strength (A) | 5/07/2025 | 4.2.2.1 Dynamic Strength Testing of Type A Anchorage Connectors | Pass |
| Residual Strength (A) | 5/07/2025 | 4.2.3.1 Residual Strength Testing of Type A, T, & D Anchorage Connectors | Pass |

This test report covers these additional products:

10710, 10710-D, 10717, 10719-D

Please contact quality@guardianfall.com for signed report.



| | TEST EQUIPMENT | |
|--------------|----------------|-------------|
| EQUIPMENT | MODEL | SERIAL |
| Load Cell | 1220ACK-25K-B | 347989A |
| Load Cell | 1210AF-10K-B | 444522A |
| Tape Measure | 56-7533 | 1052022 |
| Test Weight | 282 lb | GFP001 |
| Stopwatch | 5028 | 230581806 |
| Scale | TU | 02314063019 |

| 3.1 | Design Requirements | |
|-----------|--|------------------|
| 3.1.1a | Connection points shall support only one user or system at a time | Meets or exceeds |
| b) | A connection point eye on a type T anchorage connector shall be a closed eye with a minimum 1 inch inside radius | Meets or exceeds |
| c) | Anchorage connectors shall not have closed loops that could be mistaken for a connection point | Meets or exceeds |
| d) | Any operable gates, rings, buckles, or other hardware covered by ANSI Z359.12-2012 shall comply with ANSI Z359-12-2012 | Meets or exceeds |
| e) | Multiple connections shall only be permitted on tripod or davit style anchorages | Meets or exceeds |
| 3.1.2 | Surfaces shall be free from burrs, pits, sharp corners and roughness | Meets or exceeds |
| 3.1.3.1 | Hot-dipped galvanized steel shall conform with ASTM A123/123M | N/A |
| 3.1.3.2.1 | Type A and Type T anchorage connectors shall maintain toughness at temps between -30 degrees F and +130 degrees F. Each dynamic strength test sample shall be conditioned at -35 +/-2 C for a minimum of 8 hours and removed no more than five minutes before testing. | Meets or exceeds |
| 3.1.4.1 | Textiles shall not contain natural fibers | Meets or exceeds |
| 3.1.4.2 | If a subsystem uses stitching for connection of load-bearing components, the equipment manufacturer shall produce the stitching and cutting and meet the following requirements: | N . |
| a) | Use lock stitching | Meets or exceeds |
| b) | Secure the ends of threads by backstitching, overlapping stitching, or other methods | Meets or exceeds |
| c) | Threads used for sewing shall be physically compatible with the webbing and of a quality comparable to that of the webbing | Meets or exceeds |
| d) | Hot-cut or fuse thermoplastic materials, cord, tape, and webbing to prevent fraying | Meets or exceeds |
| e) | The thread color or shade shall contrast with that of the webbing to faciltate visual inspection | Meets or exceeds |



| 5 | Markings and Instructions | |
|---------|--|------------------|
| 5.1 | Marking Requirements | |
| 5.1.1 | General: The following markings shall appear in English on a label, marking or tag that is designed to last for the lifetime of the anchorage connector and is permanently affixed to the anchorage connector | |
| a) | The manufacturer's name and mark | Meets or exceeds |
| b) | The year of manufacture | Meets or exceeds |
| c) | Model number | Meets or exceeds |
| d) | "ANSI Z359.18" and the type | Meets or exceeds |
| e) | Markings to indicate restrictions on directions of loading, if applicable | Meets or exceeds |
| f) | Where specified by the manufacturer, the working load | Meets or exceeds |
| g) | An individual serial number or a lot or batch number that provides traceability | Meets or exceeds |
| h) | Minimum Breaking Strength, followed by "MBS." | Meets or exceeds |
| 5.1.2 | Specific: As required for the specific anchorage connector, the following markings shall appear in English on a label, marking or tag that is designed to last for the lifetime of the anchorage connectior and is permanently affixed to the anchorage connector | Meets or exceeds |
| 5.1.2.1 | An anchorage connector that incorporates a closed loop not intended for connection, but may be mistaken for a connection point shall be permanently labeled with a warning not to connect a fall protection system or suspended component to the closed loop when used in a cinching operation | Meets or exceeds |
| 5.1.2.3 | The minimum service temperature for the anchorage connector according to 3.1.3.2 | Meets or exceeds |
| 5.1.2.4 | For tripods and davit systems, the maximum number of users permitted on the system | N/A |

| Notes | 7 , Or 5 , | |
|------------|------------|--|
| 0 6 | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| 0. 9 00. 9 | | |
| | | |

| 5.2 | Instruction Requirements | |
|---------|---|-----------------|
| 5.2.1 | General: Provide the following instructions and information in English with each anchorage connector | av. |
| 5.2.1.1 | Overall: | 2 |
| a) | A statement that the anchorage connector has been tested in compliance with the requirements of ANSI/ASSE Z359.7, and caution that the ANSI compliance testing covers only the hardware and does not extend to the anchorage and substrate to which the anchorage connector is attached | Meets o |
| b) | Specifications for appropriate anchorages(s) to which the anchorage connector can be attached, including instructions on how to proceed when the user is unable to determine whether the anchorage meets the manufacturer's specification and instructions that the anchorage connector shall only be connected to anchorages that: | Meets o |
| i. | Can withstand 5,000 lb (22.2kN) without failure, except that lower strengths are acceptable when permitted by applicable legislation; or | Meets o |
| ii. | Are certified by a professional engineer as having the required strength for fall arrest or travel restraint, as applicable, or; | Meets o |
| iii. | The manufacturer may provide specifications of allowable materials including the minimum shapes, sizes and geometry of structural elements to which the anchorage connector may be fastened. A qualified person shall approve these specifications. | Meets o |
| c) | The manufacturer shall clearly label the minimum service temperature for the anchorage connector according to 3.1.3.2 | Meets o |
| d) | The manufacturer shall supply complete specifications for fasteners | Meets of exceed |
| e) | The anchorage type | Meets of exceed |
| f) | The permitted uses of the anchorage connector | Meets of exceed |
| g) | The connection point(s), working load limit | Meets of exceed |
| h) | The material used in the anchorage connector's construction | Meets of exceed |
| i) | The length of the anchorage connector and any other dimensions that may affect its compatibility with anchorage to which it may be connected | Meets of exceed |
| j) | The manufacturer shall make available upon request information for the design of systems, such as AAF and/or force vs. displacement curve(s) for the device | Meets of exceed |
| k) | A statement that only one fall protection system or positioning system may be attached to an individual connection point | Meets o |
| I) | Specification providing the intended directions(s) of loading of the anchorage connector | Meets of exceed |
| m) | A complete list of the anchorage connector components provided by the manufacturer at the time of sale | Meets of exceed |
| n) | A warning against unauthorized alterations, relocations or additions to the anchorage connector | Meets o |

| Notes | . 1911. 63 | 1 | | 0,30 | |
|-------|------------|---|--|------|--|
| | | | | | |
| 0, | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |



| 5.2.1.2 | Use: | |
|---------|---|------------------|
| a) | Instructions on proper installaion and use, including, but not limits to, compatibility with other fall protection components | Meets or exceeds |
| b) | The length of the anchorage connector and any other dimensions that may affect its compatability with anchorages to which it may be connected | Meets o exceeds |
| c) | Where applicable, directions regarding the appropriate length of lanyard to use with the anchorage connector to compensate for the additional length that it may add to the lanyard | Meets o |
| d) | Permitted and forbidden uses, including clear description of and the recommended ways of dealing with applicable compatibility concerns | Meets o |
| e) | A warning to remove any surface contamination such as concrete, stucco, roofing material, etc., that could accelerate cutting or abrading of attached components | Meets o |
| f) | Warnings concerning environments and conditions that may degrade the anchorage connector | Meets o |
| g) | Training requirements | Meets o |
| 5.2.1.3 | Inspection and Field Testing: | |
| a) | Instructions on testing, if needed | N/A |
| b) | Where applicable, directions for the installer to performs and document proof testing upon installation. Directions shall include proof load forces and acceptable methods | N/A |
| c) | Field serviceability testing: The manufacturer shall provide guidelines for how often field load testing must be undertaken to prove that the anchorage connector continues to be adequately secured to the structure. These guidelines shall include recommended methods for testing, including the direction and point of application of test loads | N/A |
| d) | The recommended frequencies and procedures for inspection, maintenance, and when applicable, testing | N/A |
| e) | Instructions for inspecting and servicing an anchorage connector after it is subjected to a fall or an inspection reveals an unsafe condition | Meets o |
| f) | If applicable, guidelines for retirement of the anchorage connector | N/A |
| g) | The action to be taken if an inspection of an anchorage connector reveals an unsafe condition | Meets o |
| h) | The action to be taken after the anchorage connector is subjected to a fall | Meets o |
| i) | Criteria for removal of an anchorage connector from service if deformed from its original installed configuration | Meets o |
| 5.2.1.4 | Cinching and Non-Cinching Style Anchorage Connectors | |
| V | Where the anchorage connector includes an abrasion pad, provide directions that the abrasion pad shall be installed between the anchorage and the load bearing strap | N/A |
| AV | The proper method of installing the anchorage connector including, as applicable for non-cinching anchorage connectors, the maximum angle permitted between connection legs | N/A |

| Notes | 0 / 6 / Vb. | W D | 6, 0 | 12, 45 | |
|------------|-------------|-------|------|--------|--|
| 10 July 1 | | | | | |
| Or Charles | | | | | |
| N. 6. 6 | | | | | |
| 15 35 W | | | | | |
| | | | | | |
| 1 2 10 6 | | | | | |
| W. A . O. | | 2. 6. | | 42 | |



4.2.1.1 Static Strength Testing of Type AAnchorage Connectors requirements per 3.2.1.1

requirements per 3.2.1.1

- a) A new anchorage connector may be used for each test
- b) The test force shall be 5,000 pounds (22.2kN) +50/-0 pounds (+0.22/-0kN). Apply these forces in accordance with the requirements of 4.1.2.
- c) Install the anchorage connector on the test anchorage in accordance with the requirements of 4.1.2
- d) Apply the load to the anchorage connector in the direction(s) of loading specified in 4.1.2.5
- e) Apply the load at a rate not greater than 2 inches (51mm) per minute. Maintain the load above 5,000 pounds (22.2kN) for at least 3 minutes
- f) Release the load
- g) Evaluate the test results per 3.2.1.1

| 4.2.1.1 Static Strength Testing of Type A Anchorage Connectors requirements per 3.2.1.1 | | | | | |
|---|----------------|----------------|----------------|--|--|
| Samples | Sample # 01 | Sample # 02 | Sample # 03 | | |
| Anchorage Connector Withstands Applied Load for >3 mins | Yes | Yes | Yes | | |
| Actual load applied (lb) | 5011.23 | 5009.82 | 5007.77 | | |
| If gates are present, no seperation more than 1/8" | N/A | N/A | N/A | | |
| Result/Assessment | Pass | Pass | Pass | | |

4.2.2.1 Dynamic Strength Testing of Type AAnchorage Connectors requirements per 3.2.2.1

- a) Install the anchorage conenctor, conditioned according to the applicable requirements of this section, on the test anchorage in accordance with the requirements of 4.1.2.
- b) Connect one end of the test lanyard to the connection point of the anchorage connector to be loaded or to the arrest force measuring instrumentation, as applicable
- c) Connect the other end of the test lanyard to the test weight specified in 4.1.3
- d) Raise the test weight to achieve a free-fall distance of 3, +0.1/-0, ft (0.9, +0.03/-0m)
- e) Release the test weight by means of the quick-release mechanism
- f) Evaluate the test results per 3.2.2.1

| 4.2.2.1 Dynamic Strei Anchorage requirement | Connectors | 5 | A |
|--|----------------|----------------|----------------|
| Samples | Sample # 04 | Sample # 05 | Sample # 06 |
| Anchorage Connector arrests test weight | Yes | Yes | Yes |
| If gates are present, no seperation more than 1/8" | N/A | N/A | N/A |
| Result/Assessment | Pass | Pass | Pass |

4.2.3.1 Residual Strength Testing for Type A Anchorage Connectors requirements per 3.2.2.1

- a) Install the anchorage conenctor, conditioned according to the applicable requirements of this section, on the test anchorage in accordance with the requirements of 4.1.2.
- b) Connect one end of the test lanyard to the connection point of the anchorage connector to be loaded or to the arrest force measuring instrumentation, as applicable
- c) Connect the other end of the test lanyard to the test weight specified in 4.1.3
- d) Raise the test weight to achieve a free-fall distance of 3, +0.1/-0, ft (0.9, +0.03/-0m)
- e) Release the test weight by means of the quick-release mechanism
- f) Evaluate the test results per 3.2.2.1

| 4.2.3.1 Residual Strength Testing for Type A Anchorage Connectors requirements per 3.2.2.1 | | | | |
|--|----------------|----------------|----------------|--|
| Samples | Sample # 04 | Sample # 05 | Sample # 06 | |
| Anchorage connector arrests test weight | Yes | Yes | Yes | |
| Anchorage connector supports test weight for minimum one minute | Pass | Pass | Pass | |
| If gates are present, no separation more than 1/8" | N/A | N/A | N/A | |
| Result/Assessment | Pass | Pass | Pass | |





Notes

All testing was completed with the samples installed around metal rebar and poured in place in concrete.



LabelsApplicable to all part #s

90082 Rev. I - 1



Concrete Anchor Strap

ANSI/ASSP Z359.18, OSHA 1910.140 & 1926.502

▲ WARNING

Prior to use, read and understand all instructions provided by manufacturer at time of shipment for proper use, inspection maintenance, and inspection. Alteration, abuse or misuse of this product may result in serious injury or death.

Avoid contact with hazards, including, but not limited to, heat, chemicals, electricity, and sharp or abrasive edges and surfaces. NEVER make incompatible connections.

PFAS equipment must be selected and deemed compatible with Concrete Anchor Strap by a Competent Person.

Type A Anchorage Connector

User Weight Range (including tools and equipment): 100-420 lb (45-191 kg)

Minimum Breaking Strength (MBS): 5,000 lb (22,2 kN)

Minimum Service Temperature: -30° F (-34° C)

Materials: polyester, nylon, and galvanized steel

MAXIMUM 1 CONNECTION PER ANCHOR CONCRETE MUST BE CURED PRIOR TO USE

90082 Rev. I - 2

Inspection Grid

User must inspect prior to EACH use. Competent Person must complete formal inspection every 12 months.

Competent Person to inspect and initial.

Product lifetime is indefinite provided equipment passes all pre-use and Competent Person inspections.

If equipment fails inspection,
IMMEDIATELY REMOVE FROM SERVICE

| Date | | |
|--------------------|--|--|
| | | |
| | | |
| | | |
| | | |
| | | |
| Date of First Use: | | |
| | | |

DO NOT REMOVE LABELS

90082 Rev. I - 3

A WARNING

Never connect fall protection system or suspended component to closed loop end!

| Ν | ote | ς |
|---|-----|---|



