

LADDER HOOK WITH WHEEL




Part #: 2480; 2481

Instructions



Part # 2481



Ladder Requirements

- ⚠ WARNING** Failure to read and follow instructions on the use of this product could result in serious personal injury. This product must be used in strict compliance with Local, State and federal OSHA regulations. Be safety conscious.
- ⚠ WARNING!** Inspect ladder hook before each use, if parts are bent, cracked, or damaged immediately remove from use.
- ⚠ NOTE** This product is not recommended for use on roofs with vented ridges.

✗ Do not throw instructions away.

⚠ Read and understand instructions before using this equipment.

Maintenance, Cleaning, and Storage

Cleaning after use is important for maintaining the safety and longevity of the system. Remove all dirt, corrosives, and contaminants from the kit before and after each use. If kit cannot be cleaned with plain water, use mild soap and water, then rinse and wipe dry. NEVER clean kit with corrosive substances.

When not in use or during transport, store equipment where it will not be affected by heat, light, excessive moisture, chemicals, or other degrading elements.

Installation and Use:

⚠ WARNING! Metal conducts electricity. Keep metal ladder and ladder hooks away from electrical circuits. Acid damages aluminum. Never use a ladder when using acid. Failure to follow these guidelines could result in injury or death.

⚠ Always install two ladder hooks per ladder.

⚠ Do not overload – do not exceed rated ladder capacity. Overloading could cause injury.

■ Step 1

Install two #2480 or two #2481 Ladder Hooks as pictured onto the top two rungs of the ladder. Secure in place by clamping the bottom of the ladder hook around the lower of the two ladder rungs. Then secure roof hook to the upper ladder rung with the rung clip by tightening the wing nut and bolt. Check to ensure that each hook is resting up against a corresponding side-rail of the ladder.

■ Step 2

With the hook facing up, slide the ladder up past the peak of the roof. Turn the ladder over so that the two hooks rest on the opposite side of the roof peak. The ladder should be fl at on the roof with the angle clip at right angle to the hook and resting securely against the roof's surface. Always install two ladder hooks per ladder.

Part #	Description	Weight
2480	Ladder Hook (no wheel)	11 lb (4,9 kg)
2481	Ladder Hook with wheel	14 lb (6,3 kg)



USA

607 East Sam Houston Parkway South
Suite 800
Pasadena, TX 77503
800 466 6385
customer.service@guardianfall.com

CANADA

580 Notre Dame Avenue, Unit 16
Sudbury, ON
P3C 5L2
800 466 6385
customer.service@guardianfall.com

WARRANTY: Guardian warrants to Buyer that all products are free from defects in material, workmanship, and design (if a Supplier-responsible design), however this warranty does not cover conditions resulting from normal wear and tear, neglect, abuse, accident or otherwise. Guardian's obligations under this warranty apply for the lifetime of the products and are limited to the replacement of product only. This warranty is not transferable to any other Guardian service and does not apply to product that is resold after having been put into service. No other person, firm, entity, or the like is authorized to assume or assign for Guardian any other liability in connection with the sale or use of Guardian's products. Furthermore, this warranty is void if any product is changed or altered in any way, or if the product is used in a manner other than for which it is intended. There are no implied warranties of merchantability or fitness for a particular purpose, which are specifically disclaimed.
