

CORNER BUDDY LADDER STABILIZER

Part #: 2470

Assembly and Use Instructions




Fig. A

Parts List		
#	Description	Qty.
1	U-Bolts	2
2	Corner Buddy	1
3	Mounting Brackets	2
4	Wing Nuts	2
5	End Caps	2




Fig. B

Assembly Instructions

1. Lay ladder flat on the ground with the "Wall Side" facing down.
2. Lift the end of ladder and position the Corner Buddy in desired mounting position under top rung. The ladder should rest in place over the stabilizer bar.
3. Place U-Bolts (1) over the side of the ladder near the ladder rung, and over the Corner Buddy (2) at a 45° angle. **NOTE:** Position U-Bolts so they straddle the ladder side rail and top ladder rung as shown in Fig. B above.
4. Fasten the stabilizer (2) to the inside of the ladder using two mounting brackets (3) and four wing nuts (4).
5. Hand tighten wing nuts (4).
6. Flip the ladder/stabilizer over and press the rubber end caps on the ends of the stabilizer tube. Tap the caps on with a rubber mallet if needed to assure a tight fit.

*See Additional Use Instructions on next page



Additional Use Instructions

✗ **Do not throw instructions away.**

⚠ **Read and understand, and follow instructions before using this equipment. Failure to follow instructions may result in personal injury or death.**

Max. User Weight: 300 lb. (136.2 kg). Never exceed ladder maximum weight capacity!

Corner Buddy **MUST** be installed between ladder and work surface.

Follow ladder instructions for recommended angle against vertical wall.

⚠ **NOTE** When used on outside corners, bottom of ladder must be 6 in (15.24 cm) farther away from the wall than the distance recommended by the ladder manufacturer.

⚠ **NOTE** When used against walls, bottom of ladder must be 18 in (45.72 cm) farther away from the wall than the distance recommended by the ladder manufacturer.

Inspect for damaged or missing parts and that all wing nuts are tightened before each use.

Never use Corner Buddy with missing/damaged parts or attempt to repair Corner Buddy.

⚠ **WARNING** Never use near any electrical current.

Do not stand on Corner Buddy or use as support for planks.

Check that all four ends of the ladder and Corner Buddy are firmly supported to prevent excessive movements. Do not use Corner Buddy on any slippery surface.

Securely engage ladder locks before climbing.

Always work centered on ladder, never overreach beyond Corner Buddy to right or left.

Corner Buddy must be centered on corners.

USA

607 East Sam Houston Parkway South
Suite 800
Pasadena, TX 77503
800 466 6385
customer.service@guardianfall.com

CANADA

580 Notre Dame Avenue, Unit 16
Sudbury, ON
P3C 5L2
800 466 6385
customer.service@guardianfall.com

WARRANTY: Guardian warrants to Buyer that all products are free from defects in material, workmanship, and design (if a Supplier-responsible design), however this warranty does not cover conditions resulting from normal wear and tear, neglect, abuse, accident or otherwise. Guardian's obligations under this warranty apply for the lifetime of the products and are limited to the replacement of product only. This warranty is not transferable to any other Guardian service and does not apply to product that is resold after having been put into service. No other person, firm, entity, or the like is authorized to assume or assign for Guardian any other liability in connection with the sale or use of Guardian's products. Furthermore, this warranty is void if any product is changed or altered in any way, or if the product is used in a manner other than for which it is intended. There are no implied warranties of merchantability or fitness for a particular purpose, which are specifically disclaimed.
