LED Wall Sconce

AT6610-BG-UNV


START FROM HERE

- Make sure **POWER** is **COMPLETELY OFF** at the fuse box
- Have your fixture installed by a qualified licensed electrician
- Prepare everything in a clear area
- Wear gloves at all times during this installation
- · Read instructions carefully before you start assembly
- Keep this installation sheet for future reference

Technical Support: 1-855-855-8926

- 1. Remove the fixture from its original packaging
- Remove the mounting plate (1c) from within the canopy (2a) by removing the canopy screws (2b)
- **3.** Attach the mounting plate (1c) to the electrical junction box (1a) using junction box screws (1e) provided in the hardware package.

- Please Note:
- This Kuzco LED fixture comes with pre-wired LED module(s).
- Unless instructed to do so, please do not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage.
- For dimming, an ELV (Electronic Low Voltage) or TRIAC type of dimmer is required.
- 120-277V input
- Brushed Gold Finish Only
- Dry Locations Only
 - Make proper electrical connections (black to hot "L", white to neutral "N", ground to "GND") with wire nuts (1b) provided in hardware package
 - **5.** Attach canopy (2a) to mounting plate (1c) with canopy screws (2b)





19054 28th Avenue Surrey, BC Canada V3Z 6M3 T: 604 538 7162 TF: 1-855 85 KUZCO F: 604 538 7196 W: kuzcolighting.com 20241114