MP502204-09

1.855.855.8926 technicalsupport@aloralighting.com

# WARNINGS AND CAUTIONS

- · Make sure POWER is COMPLETELY OFF at the fuse box
- · Have your fixture installed by a qualified licensed electrician
- · Prepare everything in a clear area
- · Wear gloves at all times during this installation
- · Read instructions carefully before you start assembly
- · Keep this installation sheet for future reference

### Please Note:

- · This Alora Mood LED fixture comes with pre-wired LED module(s)
- · Unless instructed, Do Not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage
- · For dimming, an ELV (Electronic Low Voltage) type of dimmer is required
- · 120V input

## NOTICE

- The important safeguards and instructions outlined in this sheet cannot cover all possible conditions and situations that may occur. It must be understood that caution and certain care factors must be followed. These instructions are provided for your safety and we highly recommend that a licensed, trained electrician install this unit.
- This fixture is designed to be mounted on a correctly installed standard round or octagon box OR through a wiring box with a plaster frame. The box must be securely mounted to the structure of the building. The crossbar and hardware supplied should be used, directly mounting the fixture to the outlet box may make it impossible to correctly align the fixture

# ASSEMBLY INSTRUCTIONS

### Step 1

Remove fixture from its original package.

Separate mounting plate (1c) from canopy (2a) by removing decorative nuts (2c).

## Step 3

Align mounting plate screws (1d) to desired orientation, and then attach mounting plate (1c) to electrical junction box (1a) using junction box screws provided (1e) in hardware package.

## Step 4

Secure mounting plate (1c) to mounting surface with screws (1g) and anchors (1f)

To change fixture height, push and hold wire gripper (2g), slide wire to desired length and then release wire gripper (2g) to secure.


Make proper electrical connections (black to hot "L", white to neutral "N", ground to "GND") with wire nuts (1b) provided in hardware package.

## Step 7

Secure bottom fixture (3b) to top fixture (3a) by threading clockwise.

Align and insert mounting plate screws (1d) through holes on canopy (2a), secure with decorative nuts (2c).

You are now ready to enjoy your fixture.





P. 1.855.855.8926

CANADA: 19054 28th Ave., - Surrey, BC V3Z 6M3 USA: 3035 E. Lone Mountain Rd. - Las Vegas, NV 89081

www.aloramood.com

20250624