

REPLACEMENT PARTS LIST

SINGLE PACKAGE HEAT PUMP

Q95RD SERIES

208 / 230 V, SINGLE PHASE, 13.4 SEER2 MODELS



IMPORTANT

- This document is primarily intended to assist qualified individuals experienced in the proper repair or servicing of this appliance. Only factory authorized parts or accessory kits may be used with this product. Improper installation, service, adjustment, or maintenance may cause explosion, fire, electrical shock or other hazardous conditions which may result in personal injury or property damage.
- Some local codes require licensed installation / service personnel to service this type of equipment. Under no circumstances should the equipment owner attempt to install parts or service this equipment. Failure to comply with this warning could result in property damage, personal injury, or death.

Q95RD SERIES SINGLE PACKAGE HEAT PUMP 208 / 230 V, SINGLE PHASE, 13.4 SEER2 MODELS

ITEM	DESCRIPTION	Q95RD-024K	Q95RD-030K	Q95RD-036K	Q95RD-042K	Q95RD-048K	Q95RD-060K
		1044691	1044692	1044693	1044694	1044695	1044696
1	ACCESS FITTING (NOT SHOWN)	663812R	663812R	663812R	663812R	663812R	663812R
2	ACCUMULATOR	668793R	668793R	668793R	668794R	668794R	668794R
3	AMBIENT SENSOR (NOT SHOWN)	624780R	624780R	624780R	624780R	624780R	624780R
4	BLOWER FOOT	1048848R	1048848R	1048848R	1048848R	1048848R	1048848R
5	BLOWER HOUSING	D07482R	D07482R	D07482R	D07482R	D07482R	297217R
6	BLOWER PANEL ASSEMBLY	D03523JR	D03523JR	D03523JR	D03525JR	D03525JR	D03525JR
7	BLOWER MOTOR	104922201R	104922202R	104922203R	104922204R	104922205R	104922206R
8	BLOWER MOTOR MOUNT KIT (NOT SHOWN)	913871	913871	913871	913871	913871	903489
9	BLOWER WHEEL (10 X 8)	667037R	667037R	667037R	667037R	667037R	—
	BLOWER WHEEL (11 X 8)	—	—	—	—	—	667258R
10	COIL SENSOR (NOT SHOWN)	624812R	624812R	624812R	624838R	624838R	624838R
11	COMPRESSOR	1045058R	1045060R	1045030R	1045686R	1045687R	1045689R
12	COMPRESSOR COVER	D02893JR	D02893JR	D02893JR	D02895JR	D02895JR	D02895JR
13	COMPRESSOR MOLDED PLUG (NOT SHOWN)	1045995R	1045995R	634660R	1045760R	1045760R	1045761R
14	CONDENSER COIL	664865R	664865R	664865R	1006699R	664924R	664904R
15	CONDENSER MOTOR	622164	622164	622757R	622757R	622757R	922022
16	CONTACTOR (NOT SHOWN)	1046813R	1046813R	1046813R	1046814R	1046814R	1046815R
17	CONTROL PANEL COVER	D02873JR	D02873JR	D02873JR	D02875JR	D02875JR	D02875JR
18	CORNER PANEL	D04363JR	D04363JR	D04363JR	D04365JR	D04365JR	D04365JR
19	CORNER POST	D09993JR	D09993JR	D09993JR	D09999JR	D09999JR	D09999JR
20	CRANKCASE HEATER (NOT SHOWN)	632509R	632509R	632509R	632509R	632509R	632509R
21	DEFROST BOARD (NOT SHOWN)	1045845R	1045845R	1045845R	1045845R	1045845R	1045845R
22	DISTRIBUTOR ASSEMBLY (INDOOR) (ORIFICE SIZE SHOWN UNDER SKU)	664753R .053	664516R .056	664595R .062	664689R .068	664599R .074	664782 .082
23	DISTRIBUTOR ASSEMBLY OUTDOOR) (ORIFICE SIZE SHOWN UNDER SKU)	1045842R .038	1017674 .042	664917R .045	664514R .048	1046652R .052	664517R .060
24	DRAIN PAN	669187R	669187R	669187R	669187R	669187R	669187R
25	DRAIN TUBE	663713R	663713R	663713R	663713R	663713R	663713R
26	DUAL CAPACITOR (NOT SHOWN)	01-0083	01-0097	01-0084	01-0278	01-0278	1045801R
27	EVAPORATOR COIL	1045833R	1045833R	1045837R	1045832R	1045836R	1045836R
28	EVAPORATOR COIL BRACKET KITS (NOT SHOWN)	1049215	1049215	1049215	1049217	1049218	1049218
29	FAN BLADE	667355R	667355R	667356R	667356R	667319R	667319R
30	FAN GRILL	669404R	669404R	669404R	669404R	1046803R	1046803R
31	FAN GRILLE TOP CAP	275291PSLR	275291PSLR	275291PSLR	275291PSLR	275291PSLR	275291PSLR
32	FILTER DRIER	669762R	669762R	669762R	669762R	669762R	669762R
33	FORMED CONDENSER COIL GRILL	2A8154R	2A8154R	2A8154R	2A8156R	2B4831R	2B4831R
34	FUSE, 3-AMP (NOT SHOWN)	632261R	632261R	632261R	632261R	632261R	632261R
35	HIGH PRESSURE SWITCH	1007368R	1007368R	632473R	1007368R	1007368R	1007368R
36	HOT GAS BYPASS VALVE	669964R	669964R	669964R	669965R	669965R	669965R
37	HOT GAS BYPASS VALVE COIL	670027R	670027R	670027R	670027R	670027R	670027R
38	LEAK DETECTION SENSOR (LDS)	1046847R	1046847R	1046847R	1046847R	1046847R	1046847R
39	LOW PRESSURE SWITCH	1023981R	1023981R	1023983R	1023981R	1023981R	1023981R
40	OUTDOOR THERMOSTAT (LIMIT) (NOT SHOWN) (NOT FACTORY INSTALLED IN ALL MODELS)	1022925R	1022925R	1022925R	1022925R	1022925R	1022925R
41	"P"-TRAP	669211R	669211R	669211R	669211R	669211R	669211R
42	REAL PANEL	D03465JR	D03465JR	D03465JR	D03469JR	D03469JR	D03469JR
43	REPLACEMENT HAIL GUARD KIT (NOT SHOWN)	917206	917206	917206	917206	917206	917206
44	REVERSING VALVE	1045280R	1045280R	1045280R	1045281R	1045281R	669465R
45	REVERSING VALVE COIL	669471R	669471R	669471R	669471R	669471R	669471R
46	SET OF WIRES (NOT SHOWN)	104943201R	104943201R	104943201R	104943201R	104943201R	104943203R
47	TOP PAN ASSEMBLY (LEFT)	D03570JR	D03570JR	D03570JR	D03570JR	D03570JR	D03570JR
48	TOP PAN ASSEMBLY (RIGHT)	D07090JR	D07090JR	D07090JR	D07090JR	D07091JR	D07091JR
49	THERMOSTAT TERMINAL BOARD (NOT SHOWN)	1048561R	1048561R	1048561R	1048561R	1048561R	1048561R
50	TRANSFORMER (NOT SHOWN)	621709R	621709R	621709R	621709R	621709R	621709R

Please specify the correct Model No., Serial No, and Part No.(s) when ordering parts from the nearest authorized dealer or service center.

