

FORD/LINCOLN/MERCUY
2005-Up

****READ THIS FIRST****

Changing Sources (iPod, HD Radio, *Satellite Radio, Aux)

- Press the AUX or SIRIUS button repeatedly to toggle through the Media Gateway sources.
- When the AUX or SIRIUS button is pressed the radio will display SAT 1, 2 or 3 for a moment then you will see the mode. (ex: HD-FM1, IPOD, AUX or SAT)

*if available



iPod



◀ Seek

- Press to go back to the previous track
- Press to go back to the previous option in the browse menu

Preset 2


- Press to enter the browse menu
- Press to make a selection while in the browse menu

Preset 1

- Press to go back one step while in the browse menu

Preset 3

- Press to exit the browse menu



Seek ▶

- Press to advance to the next track
- Press to advance to the next option in the browse menu

Preset 5

- Press to rewind the track that is playing

Aux/Sirius

- Press to toggle through the Media Gateway/Satellite Radio modes

Preset 6

- Press to fast forward the track that is playing

Preset 4

- Press to toggle through display modes

Browsing Example:

To select the song "Star-Spangled Banner" through the Artist category

Press Preset 2 to enter into the browse menu. The radio will display "PL:LIST"



Press the SEEK ▶ button until radio displays "AR:ARTIST". Press Preset 2 to select. Radio will display "AR:ALL"



Press the SEEK ▶ button until radio displays "AR:Francis Scott Key". Press Preset 2 to select. Radio will display "AL:ALL"



Press the SEEK ▶ button until radio displays "AL:Patriot Hits Vol. 1". Press Preset 2 to select. Radio will display "TR:ALL"



Press the SEEK ▶ button until radio displays "TR:Star-Spangled Banner". Press Preset 2 to select. Song will begin to play and display will show track info.

(Actual Radio Appearance may differ from representation.)

QRC001




****READ THIS FIRST****

Changing Sources (iPod, HD Radio, *Satellite Radio, Aux)

- Press the AUX or SIRIUS button repeatedly to toggle through the Media Gateway sources.
- When the AUX or SIRIUS button is pressed the radio will display SAT 1, 2 or 3 for a moment then you will see the mode. (ex: HD-FM1, IPOD, AUX or SAT)

*if available



Text/Scan

- Press to switch between artist and song title

Seek

- Press to seek down to the next available station
- Press to tune down one station

Aux/Sirius

- Press to toggle through the Media Gateway/Satellite Radio modes

Seek

- Press and hold to switch between seek & tune modes
- Press to seek up to the next available station
- Press to tune up one station

Presets 1-6

- Press and hold to store a station into memory
- Press and release to recall a station in memory

HD RADIO EXAMPLE

To select an HD radio station.

Press the SEEK ► button to get to the desired station. The Radio will auto lock on to an HD Radio Station if available; example: 92.5 HD1 MHZ. When locked into an HD Radio Station, press the SEEK ► button to access multi-cast HD Station(s) (if available); example: 92.5 HD2 MHZ

To store a radio station into preset memory.

Press and hold any preset (1-6) to store a station into memory. The screen will display "PR:SAVED"

To recall a station stored into preset memory.

Press and release the desired preset that you wish to recall.

(Actual Radio Appearance may differ from representation.)