


FORD/LINCOLN/MERCUY
Select 2009
Navigation Radios




iPod

****READ THIS FIRST****

Changing Sources (iPod, HD Radio, SYNC)

- Press the MEDIA button on the face of the radio
- Press the "USER DEVICE" icon on the screen
- Press the "SOURCE" icon on the screen until the radio displays "HD-FM" or "HD-AM"



Seek ▲

- Press to advance to the next track

Seek ▼

- Press to go back to the previous track

IIcon

- Press and hold to rewind the track that is playing

Tune Knob

- Turn clockwise to advance to the next option in the browse menu
- Turn counter-clockwise to go back to the previous option in the browse menu

Text Icon

- Press to enter the browse menu or to make a selection while in the browse menu

Source Icon

- Press to toggle through Media Gateway/SYNC sources

IIcon.

- Press and hold to fast forward the song that is playing

Browsing Example:

To select the song "Star-Spangled Banner" through the Artist category

Press the "Text" icon to enter into the browse menu. The radio will display "PL:LIST"

Turn the Tune Knob until radio displays "AR:ARTIST". Press the "Text" icon to select. Radio will display "AR:ALL"

Turn the Tune Knob until radio displays "AL:Patriot Hits Vol. 1". Press the "Text" icon to select. Radio will display "AL:ALL"

Turn the Tune Knob until radio displays "TR:Star-Spangled Banner". Press the "Text" icon to select. Radio will display "TR:ALL".

Turn the Tune Knob until radio displays "TR:Star-Spangled Banner". Press the "Text" icon to select. Song will begin to play and display will show track info.

(Actual Radio Appearance may differ from representation.)

QRC029


FORD/LINCOLN/MERCURY
Select 2009
Navigation Radios



****READ THIS FIRST****

Changing Sources (iPod, HD Radio, SYNC)

- Press the MEDIA button on the face of the radio
- Press the "USER DEVICE" icon on the screen
- Press the "SOURCE" icon on the screen until the radio displays "HD-FM" or "HD-AM"



Tune Knob

- Turn clockwise to tune up one station
- Turn counter-clockwise to tune down one station

Source Icon

- Press to toggle through Media Gateway/SYNC sources

Music Library Icon

- Press to enter the preset menu

Seek ▲

- Press to seek up to the next available station

Seek ▼

- Press to seek down to the next available station

HD RADIO EXAMPLE

To select an HD radio station.

Press the SEEK ▲ button to get to the desired station. The Radio will auto lock on to an HD Radio Station if available; example: 92.5 HD1 MHZ. When locked into an HD Radio Station, press the SEEK ▲ button to access multi-cast HD Station(s) (if available); example: 92.5 HD2 MHZ

To store a radio station into preset memory.

Press the "MUSIC LIBRARY" icon to enter the Preset Menu. Press the "MAIN MENU" icon, then press the icon that represents where you want to store the preset. Screen will display "PR:SAVED".

To recall a station stored into preset memory.

Press the "MUSIC LIBRARY" icon to enter the Preset Menu. Press the icon that represents the station you want to recall.

(Actual Radio Appearance may differ from representation.)