

**IMPORTANT, RETAIN FOR FUTURE REFERENCE:
READ CAREFULLY.**

⚠ WARNING

- Make sure Bleacher Hook is secured to bleacher or bench before sitting - failure to do so may result in personal injury.
- Bleacher Hook is not designed to bear user's weight when leaning against backrest.
- Do not use while seated on the top row of bleachers. Do not use seat if bleacher or bench does not allow for use of the Bleacher Hook.

⚠ WARNING

WEIGHT LIMIT: 136 kg / 300 lb

Exceeding weight limit and/or product misuse may cause seat or seat components to fail and may result in personal injury or death.


USE AND CARE

Clean with sponge, mild soap and water. Dry with white cloth. Do not use colored towels as colors may bleed onto the seat. Do not use abrasive cleaners or scrub pads as they may damage the canvas and/or frame. Make sure chair is fully dry before storing. It is strongly recommended the chair be stored under cover or indoors.

Outdoor Camping Use Only

MADE IN CHINA

- Holding the seat bottom, pull the seat back away from the bottom to open.
 - Rotate the Bleacher Hook (A) away from the seat bottom as shown in image. Place seat on bleacher or bench. Slide the Bleacher Hook under bleacher or bench to secure.
- The base seat should stay flat on bleacher or bench while in use.



FOR ADULT USE ONLY. This chair is intended for use on bleachers, benches, or on flat, stable ground. User should always sit squarely in chair seat. Do not tilt back in chair. Improper use may result in tipping and personal injury.

- Do not put fingers under seat bottom when in use.
- Do not use around heat sources or open flame.