

IMPORTANT: RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

⚠WARNING

- Make sure Bleacher Strap is secured to bleacher or bench before sitting - failure to do so may result in personal injury.
- Bleacher Strap is not designed to bear user's weight when leaning against backrest.
- Do not use while seated on the top row of bleachers. Do not use seat if bleacher or bench does not allow for use of the Bleacher Strap.

⚠WARNING

WEIGHT LIMIT: 113.4 kg / 250 lb


Exceeding weight limit and/or product misuse may cause seat or seat components to fail and may result in personal injury or death.

See reverse for important use and care instructions

CAUTION

User should always sit squarely in chair seat. Do not tilt back in chair. This chair is intended for use on bleachers, benches, or on flat, stable ground. Improper use may result in tipping and personal injury. Make sure bleacher strap is secured to bleacher or bench before sitting - failure to do so may result in personal injury. Do not put fingers under seat bottom when in use.

BLEACHER STRAP WARNING: Bleacher strap is intended to stabilize the stadium seat on bleacher or bench. It is not designed to bear user's weight when leaning against backrest. Base of seat should stay flat on bleacher or bench while in use.



Correctly secured bleacher strap
as seen from beneath bleacher


Cascade Mountain Technologies LLC
www.cascademountaintech.com

For Parts and Customer Service:
customercare@cascademountaintech.com

MADE IN CAMBODIA


FOLDING FOR STORAGE OR CARRY

Tilt seatback fully forward.
Use Bleacher Straps to secure seat closed before carrying with backpack straps.




RECLINING BACKREST

With chair completely flat and backpack straps facing the ground, raise seat back by tilting it forward into desired level of recline or 90° seated position.




ACTIVATING ARMRESTS

With chair completely flat and backpack straps upwards, press downward on the hinge in the middle of the armrest until the armrest "pops" into position. Turn the seat over and raise the backrest into desired position.



COLLAPSING ARMRESTS

With chair completely flat and backpack straps facing the ground, press downward on the hinge in the middle of the armrest until the armrest "pops" into position. Raise the backrest into desired position.



See reverse for important safety warnings and care instructions

USE AND CARE

Intended for Outdoor Use. Clean with sponge, mild soap, and water. Do not use abrasive cleaners or scrub pads as they may damage the seat material. Make sure chair is fully dry before storing. Store under cover or indoors.