

ATTACHMENT TAPE & D-RING WEBBING

Installation and Usage Instructions

Please read instructions carefully and fully before installation and/or usage.



Initial Setup Instructions

Required Equipment: Ty-Flot D-ring Webbing (Sold Separately), Scissors

1. Select a tool of appropriate size and shape from the Tool Selection Guide.
2. Make sure the tool is free of foreign material or sharp edges. Sharp edges may cut the tape.
3. Find a suitable tool location on the tool or the attachment that:
 - a. will not obstruct the use of the tool
 - b. will not create an additional safety hazard

Usage Instructions

1. Do not suspend a tool on its tether
2. Pull test prior to each use
3. Inspect D-Ring Webbing and Tether Tape prior to every use
4. Always use an appropriate tool tether

Remove and replace if there is any doubt to the product's integrity

SPECIAL NOTES

Additional wrapping can increase strength
Tether Attachment has been known to last for lengthy periods of time, but should be treated as a temporary, on-the-fly solution.

WARNINGS

ALWAYS WEAR APPROPRIATE PROTECTIVE EQUIPMENT. DO NOT USE THIS PRODUCT ON OR NEAR ROTATING EQUIPMENT. IMPROPER USE COULD RESULT IN DEATH OR DISMEMBERMENT. IF ANY CRACKS, RIPS OR TEARS ARE NOTED, PRODUCT REPLACEMENT IS REQUIRED.

INSTALLATION

Step 1



Choose proper tool combination from Tool Selection Guide below and a suitable tool location for the Attachment Tape.

Step 4



Continue to wrap (and stretch) from starting ledge with 50% overlap until the tape meets the opposite ledge.




If not enough tape, remove and start again.

Step 2



Cut the required amount. Separate and discard the liner. Required amounts are estimated in the Tool Selection Guide below.

Step 3



While stretching the tape wrap four revolutions near either ledge with 100% overlap. Be sure to keep label exposed.

Step 5




While stretching wrap four revolutions with 100% overlap when reaching opposite ledge.

Step 6



Complete!



Ratings (with MOL36RF):

Product No.	Tether Length	Weight Rating
DRHD	≤12" Tether (30.48cm)	6.5 lbs (2.94kg)
	>12" (30.48cm) to ≤48" (121.92cm)	2.5 lbs (1.13kg)
DRHDPL	≤12" Tether (30.48cm)	5 lbs (2.26kg)
	>12" (30.48cm) to ≤48" (121.92cm)	2 lbs (0.90kg)
DRHDDT	≤12" Tether (30.48cm)	6.5 lbs (2.94kg)
	>12" (30.48cm) to ≤48" (121.92cm)	2.5 lbs (1.13kg)
DRSM	≤12" Tether (30.48cm)	4.5 lbs (2.04kg)
	>12" (30.48cm) to ≤48" (121.92cm)	1.5 lbs (0.68kg)
DRSMPL	≤12" Tether (30.48cm)	4.5 lbs (2.04kg)
	>12" (30.48cm) to ≤48" (121.92cm)	1.25 lbs (0.56kg)

Ratings are based on cylindrical test modules in a perpendicular configuration and may or may not represent field configurations. End user must make determination of suitability.

Tool Diameter	Approx. Tape Requirement Before Stretch
0.25"	8"
0.5"	16"
1"	32"
2"	64"

For other tool sizes, multiply the average diameter by 32. If unsure of amount it is better to overestimate.

TOOL SELECTION GUIDE

Ty-Flot, Inc. • 305 Massabesic Street • Manchester, NH 03103
www.ty-flot.com • Phone: 603-669-5169 • Fax: 603-669-5113

THE DROP STOPS HERE

