


CEILING SUSPENDED



A | Prior to the installation of the fixture install 1/4-20 threaded anchors, (PROVIDED BY OTHERS), and attach ceiling couplers along with stainless steel cables, (PROVIDED BY LIGHTART).

B | Depress plunger on cable gripper and feed stainless steel cable through gripper.

C | Raise fixture to desired height and trim off excess cable.

D | Determine length between canopy and fixture, trim and strip electrical cord to the appropriate length.

E | Attach universal box adapter to junction box.

F | Feed power cord through strain relief in canopy and make all electrical connections - SEE WIRING DIAGRAM BELOW.

G | Attach the canopy to junction box with the (2) mounting screws provided. Tighten set screw on the strain relief to secure power cord.



0-10V Dimming

WIRING DIAGRAM

For illustration purposes only. Consult control manufacturer's spec. sheets for specific wiring requirements and fixture capacity.

NOTICE:

- Wire according to appropriate manufacturers wiring diagrams
- WARNING: Risk of shock from energized equipment.
- Always turn power OFF and lock out during fixture installation
- This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- SUITABLE FOR DAMP LOCATIONS
- CONTACT MANUFACTURER FOR LED REPLACEMENT

WARNING:

- LIGHTART IS NOT LIABLE FOR DAMAGE DUE TO MISWIRING 0-10 VOLT CONTROL WIRES, OR LOW VOLTAGE LED WIRES TO LINE VOLTAGE.



LED DRIVER

- Provided by LightArt
- Mounted in canopy w/ 6-32 k-lock nuts.